PSPE 330 YPT-330

SERVICE MANUAL



PSR-E333



YPT-330

* YPT-330 is an overseas export model. (YPT-330 は輸出専用モデルです。)

■ CONTENTS(目次)

SPECIFICATIONS(総合仕様)	
PANEL LAYOUT (パネルレイアウト)	5
CIRCUIT BOARD LAYOUT & WIRING	
(ユニットレイアウト & 結線図)	7
BLOCK DIAGRAM(ブロックダイアグラム)	
DISASSEMBLY PROCEDURE (分解手順)	9
LSI PIN DESCRIPTION (LSI 端子機能表)	15
CIRCUIT BOARDS(シート基板図)	17
TEST PROGRAM (テストプログラム)	21/24
BACKUP (バックアップ)	27/28
INITIALIZATION (初期化)	27/28
CONNECTING A PERSONAL COMPUTER	
(コンピューターと接続する)	29/30
TRANSFERRING DATA BETWEEN THE PSR-E333/YPT-330 and a COMPU	TER
(PSR-E333 とコンピューターの間でデータを送受信する)	31/33
SYSTEM BOOTING FLOWCHART	
(起動フローチャート)	35/36
PARTS LIST	
OVERALL CIRCUIT DIAGRAM(総回路図)	

Products names are as follows. (商品名は以下のようになります。)

For Japanese market (国内向け):

PORTATONE

For overseas market (海外向け):

DIGITAL KEYBOARD

IMPORTANT NOTICE

This manual has been provided for the use of authorized Yamaha Retailers and their service personnel. It has been assumed that basic service procedures inherent to the industry, and more specifically Yamaha Products, are already known and understood by the users, and have therefore not been restated.

WARNING: Failure to follow appropriate service and safety procedures when servicing this product may result in personal injury, destruction of expensive components and failure of the product to perform as specified. For these reasons, we advise

all Yamaha product owners that all service required should be performed by an authorized Yamaha Retailer or the

appointed service representative.

IMPORTANT: This presentation or sale of this manual to any individual or firm does not constitute authorization certification, recognition of any applicable technical capabilities, or establish a principal-agent relationship of any form.

The data provided is belived to be accurate and applicable to the unit(s) indicated on the cover. The research engineering, and service departments of Yamaha are continually striving to improve Yamaha products. Modifications are, therefore, inevitable and changes in specification are subject to change without notice or obligation to retrofit. Should any discrepancy appear to exist, please contact the

WARNING: Static discharges can destroy expensive components. Discharge any static electricity your body may have accumulated by grounding yourself to the ground bus in the unit (heavy gauge black wires connect to this bus.)

IMPORTANT: Turn the unit OFF during disassembly and parts replacement. Recheck all work before you apply power to the unit.

WARNING: This product contains chemicals known to the State of California to cause cancer, or birth defects or other reproductive harm. DO NOT PLACE SOLDER. ELECTRICAL/ELECTRONIC OR PLASTIC COMPONENTS IN YOUR MOUTH FOR ANY REASON WHAT SO EVER!

Avoid prolonged, unprotected contact between solder and your skin! When soldering, do not inhale solder fumes or expose eyes to solder/ flux vapor!

If you come in contact with solder or components located inside the enclosure of this product, wash your hands before handling food.

WARNING

distributor's Service Division.

Components having special characteristics are marked 🔼 and must be replaced with parts having specification equal to those originally installed.

🅂 印の部品は、安全を維持するために重要な部品です。交換する場合は、安全のために必ず指定の部品をご使用ください。

■ SAVING DATA (データの保存)



Saving and backing up your data

Some data items are automatically saved as backup data in the internal memory even if you turn the power off. Saved data may be lost due to malfunction or incorrect operation. Save important data to external device such as a computer.



作成したデータの保存とバックアップ この楽器の一部のデータは自動的に保存されるた め、電源を切ってもデータは消えません。ただし保 存したデータは故障や誤操作などのために失われる ことがあります。大切なデータは、コンピューター などの外部機器に保存してください。

■ SPECIFICATIONS


0: 04/:::	Dimensions	WxDxH	945 x 369 x 132 mm (37-3/16" x 14-1/2" x 5-3/16")					
Size/Weight	Weight	I.	4.9kg (10 lbs. 13 oz.) (not including batteries)					
	Number of Keys		61					
Keyboard	Touch Response		Yes					
	Type		LCD display					
Display	Backlit		Yes					
	Language		English					
Panel	Language		English					
	Tone Generation	Tone Generating Technology	AWM Stereo Sampling					
	Polyphony	Number of Polyphony (Max.)	32					
Voices	Preset	Number of Voices	140 panel voices + 13 drum/SFX kits + 344 XGlite voices					
	Compatibility		GM/XGlite					
		Reverb	9 types					
	Tunas	Chorus	4 types					
	Types	Ultra-Wide Stereo	3 types					
Effects		Harmony	26 types					
		Dual	Yes					
	Function	Split	Yes					
		Panel Sustain	Yes					
		Number of Preset Styles	106					
	Preset	Fingering	Multi fingering					
Accompaniment	116561	Style Control	ACMP ON/OFF, SYNC START, START/STOP, INTRO/ENDING/rit., MAIN/AUTO FILL					
Styles	Custom	User Styles	Yes					
	Other Feetures	Music Database	100					
	Other Features	One Touch Setting (OTS)	Yes					
	Preset	Number of Preset Songs	102					
	Recording	Number of Songs	5					
		Number of Tracks	2					
Songs		Data Capacity	Approx. 10,000 notes (when only "melody" tracks are recorded) Approx. 5,500 chords (when only "chord" tracks are recorded)					
		Recording Function	Yes					
	Compatible Data	Playback	SMF					
	Format	Recording	Original File Format					
	Lesson		[1 LISTENING, 2 TIMING, 3 WAITING], [KEYS TO SUCCESS], [PHRASE REPEAT], [CHORD DICTIONARY], [A-B REPEAT]					
		Metronome	Yes					
Functions	Overall Controls	Tempo Range	11 – 280					
	Overall Controls	Transpose	-12 - 0 - +12					
		Tuning	427.0 - 440.0 - 453.0 Hz					
	Miscellaneous	Portable Grand Button	Yes					
Storage and	Internal Memory		1.7MB					
Connectivity	Connectivity		PHONES/OUTPUT, DC IN, USB TO HOST, SUSTAIN					
Amplifiers and	Amplifiers		2.5W + 2.5W					
Speakers	Speakers		12cm x 2					
Power Supply	Power Supply		Adaptor: Users within U.S or Europe: PA-130 or an equivalent Others: PA-3C, PA-130 or an equivalent Batteries: Six "AA" size, LR6 or equivalent batteries					
	Power Consumption	on	7W (When using PA-130 power adaptor)					
	Auto Power Off Fu	nction	Yes					
Included Accessories			Music Rest Owner's Manual AC Power adaptor (PA-130 or an equivalent recommended by Yamaha)					
Optional Accesso	ries		Adaptor: Users within U.S or Europe: PA-130 or an equivalent Others: PA-3C, PA-130 or an equivalent Footswitch: FC4/FC5 Keyboard Stand: L-2C/L-2L Headphones: HPE-150/HPE-30					

■総合仕様

	寸法	幅×奥行き×高さ	945 × 369 × 132(mm)					
サイズ / 重量	質量		4.9kg (乾電池含まず)					
	鍵盤数		61					
鍵盤	タッチレスポンス		0					
	タイプ		液晶					
ディスプレイ ディスプレイ	バックライト		/IXHI					
7 1 2 2 2 1	言語		英語					
パネル	言語		日本語					
7 17170	音源	音源方式	AWM ステレオサンプリング					
		最大同時発音数	32					
音源/音色	プリセット	音色数	140 パネル音色 + 13 ドラム /SFX キット + 344XGlite 音色					
	音源フォーマット		GM/XGlite					
		リバーブ	9種類					
		コーラス	4種類					
	タイプ	ウルトラワイドステレオ	3種類					
効果		ハーモニー	26 種類					
733514		デュアル	0					
	ファンクション	スプリット	0					
		パネルサステイン	0					
		プリセットスタイル数	106					
		フィンガリング	マルチフィンガリング					
	プリセット		スタイルオン/オフ、シンクロスタート、スタート/ストップ、					
伴奏スタイル		スタイルコントロール	イントロ/エンディング /rit.、メイン/フィルイン					
	カスタマイズ	ユーザースタイル	0					
	7 0 // III =	ミュージックデータベース	100					
	その他特長	ワンタッチセッティング	0					
	プリセット	内蔵曲数	102					
		録音曲数	5					
	43 42	録音トラック数	2					
録音再生	録音	データ容量	約 10,000 音符 /1 曲、または約 5,500 コード /1 曲					
		録音機能	0					
	再生フォーマット		SMF					
	録音フォーマット		オリジナルフォーマット					
	レッスン		[ソングマスター]、[1 お手本、2 タイミング、3 マイペース]、 [フレーズ練習]、[A-B リピート]、[コード辞書]					
		メトロノーム	0					
ファンクション	全体設定	テンポ	11 ~ 280					
	工件放之	トランスポーズ	-12 ~ 0 ~ +12					
		チューニング	427.0 ~ 440.0 ~ 453.0 Hz					
	その他	ピアノボタン	0					
メモリー	内蔵メモリー		約 1.7MB					
接続端子			USB TO HOST、DC IN 12V、 ヘッドフォン / 外部出力(ステレオ標準フォン)、サステイン					
アンプ/スピーカー	アンプ出力		2.5W + 2.5W					
, , , , , , , , , , , , , , , , , , , ,	スピーカー		12cm × 2					
	電源		電源アダプター: PA-3C (またはヤマハ推奨の同等品) 電池: 単3 乾電池 (1.5V) × 6 (別売)					
電源部	消費電力		12W(電源アダプター PA-3C 使用時)					
	電池寿命		アルカリ電池で約8時間					
	オートパワーオフ	機能	0					
付属品			取扱説明書、電源アダプター(PA-3C またはヤマハ推奨の同等品)、 ソングブック、保証書、譜面立て					
オプション(別売)品	ł		ソフトケース(SCC-51/SCC-52)、キーボードスタンド(L-2L/L-2C)、 ヘッドフォン(HPE-150/HPE-30)、フットスイッチ(FC4/FC5)					

■ PANEL LAYOUT (パネルレイアウト)

■ Front Panel



- **■** Front Panel
- **①** [齿] (Standby/On) switch
- ② [MASTER VOLUME] control
- 3 [1 LISTENING 2 TIMING 3 WAITING] button
- 4 [KEYS TO SUCCESS] button
- **5** [PHRASE REPEAT] button

When the lesson mode

- **6** PART
 - [L] button
 - [R] button

When the recording mode

- 6 [REC TRACK 2] button [REC TRACK 1] button
- **⑦** [METRONOME] button
- [TEMPO/TAP] button
- 9 [SONG] button
- (VOICE) button
- (I) [STYLE] button
- Number buttons [0]–[9], [+/YES], [-/NO]
- (B) [FUNCTION] button
- [DEMO/BGM] button

- ■フロントパネル
- ❶ [凸] (スタンバイ/オン)スイッチ
- 2 [全体音量]コントロール
- 3 [1 お手本 2 タイミング 3 マイペース]ボタン
- ④ [ソングマスター]ボタン
- . **⑤** [フレーズ練習]ボタン

レッスンのとき

6 パート

[左手]ボタン [右手]ボタン

録音のとき

- (5) [録音トラック 2]ボタン [録音トラック 1]ボタン
- **⑦** [メトロノーム]ボタン
- **8** [テンポ/タップ]ボタン
- 9 [ソング]ボタン
- [楽器]ボタン
- 1 [スタイル]ボタン
- **⑫** 数字ボタン[0] ~ [9]、[+/YES]、[−/NO]
- ₿ [機能]ボタン
- [デモ/BGM]ボタン

When the Song mode

- (B) [A-B REPEAT] button
- (REW) button
- (FF) button
- (B) [PAUSE] button

When the Style mode


- (B) [ACMP ON/OFF] button
- (intro/ending/rit.) button
- MAIN/AUTO FILL] button
- (B) [SYNC START] button
- (I) [START/STOP] button
- @ [REC] button
- (PORTABLE GRAND) button
- 2 [MUSIC DATABASE] button
- [ULTRA-WIDE STEREO] button
- (SPLIT) button
- (DUAL) button
- (HARMONY) button
- 7 [TOUCH] button
- 2 Drum Kit icons

ソングのとき

- **1**5 [A-B リピート]ボタン
- [巻戻し]ボタン
- [早送り]ボタン
- № [一時停止]ボタン

スタイルのとき


- 15 [スタイル オン/オフ]ボタン
- ⑥[イントロ/エンディング/rit.]ボタン
- 1 [メイン/フィルイン]ボタン
- 18[シンクロスタート]ボタン
- ⑤ [スタート/ストップ]ボタン
- ₫ [録音]ボタン
- **②**[グランドピアノ]ボタン
- **②**[ミュージックデータベース]ボタン
- (3) [ウルトラワイドステレオ]ボタン
- ❷ [スプリット]ボタン
- ₫ [ハーモニー]ボタン
- ② [タッチ]ボタン
- 28 ドラムキット



- **■** Rear Panel
- SUSTAIN jack
- **10** USB terminal
- **1** PHONES/OUTPUT jack
- 2 DC IN jack

- ■リアパネル
- ② サステイン端子
- 30 USB端子
- ③ ヘッドフォン/外部出力端子
- ☑ DC IN端子

■ CIRCUIT BOARD LAYOUT & WIRING (ユニットレイアウト & 結線図)



No.	Unit Name (ユニット名)	Location (ロケーション)	Parts No. (部品番号)	Connector Assembly (束線名)		Destination (配線先)						
1		30	WE13850R	MK1	61H-MK-CN1	*1	*4	DMLCD-CN102	*1	*4	12P L=220	
2	LOWER KEY BED	40	WE13870R	MK2	61H-MK-CN2	*1	*4	DMLCD-CN104	*1	*4	5P L=250	
3	ASSEMBLY	50	WE13880R	MK3	61L-MK-CN5	*1	*4	DMLCD-CN103	*1	*4	7P L=190	
4		120	(WQ73930)	BATT	CONTACT SPRING (+/-)	*2	*6	PNAM1/3-CN506	*1	*7	3P	
(5)	UPPER CASE ASSEMBLY	350	WE141400	BL	BACK-LIT ASSEMBLY	*2	*5	PNAM1/3-CN501	*1	*4	2P L=70	
6		WH103	(WQ66100)	AMDM	PNAM1/3-CN503	*3	*9	DMLCD-CN108	*1	*4	11P	
7		WH104	(WQ66030)	PN1	PNAM1/3-CN502	*3	*9	PNAM2/3-CN303	*3	*9	10P	
8	PNAM	WH105	(WQ66120)	MVR	PNAM1/3-CN504	*3	*9	PNAM3/3-CN401	*3	*9	5P	
9	CIRCUIT BOARD	WH201	(WQ66140)	SP	PNAM1/3-CN505	*3	*9	SPEAKER L	*2	*5	2P	
10		WH202	(WQ66140)	SP	PNAM2/3-CN202	*3	*9	SPEAKER R	*2	*5	2P	
11)		WH301	(WQ66060)	PN2	PNAM2/3-CN301	*3	*9	DMLCD-CN106	*1	*4	13P	
12		WH302	(WW15820)	JACK	PNAM2/3-CN304	*3	*9	DMLCD-CN107	*1	*4	3P	
13	KEYBOARD ASSEMBLY	220	V869620R		61H-MK-CN3	*1	*4	61L-MK-CN4	*1	*4	12P L=210	


- * The parts with "()" in "Part No." are not available as spare parts.
- *1: Installation
- *2: Manual soldering
- *3: Dip soldering
- *4: Edge mark is adjusted to Pin 1 mark (\triangle mark).
- *5: Edge mark is adjusted to + mark.
- *6: Red wire is connected to (+) terminal. Black wire is connected to (-) terminal.
- *7: Red wire is adjusted to Pin 1 mark (\wedge mark).
- *8: Red wire is connected to (+) terminal.
- *9: Connected

Caution: Be sure to attach the removed filament tape just as it was before removal.

- * 部品番号が()で囲まれている部品は、サービス部品として準備されていません。
- *1: 差込み
- *2: 手半田
- *3: ディップ
- *4: エッジマークが1ピン側(△)
- *5: エッジマークが + 側 (+)
- *6: 赤色線材が (+) 端子、黒色線材が (-) 端子
- *7: 赤色線材が1ピン側(△)
- *8: 赤色線材が (+) 端子
- *9: 接続済

注意: 一度剥がしたフィラメントテープは、取り外す前と同じように、取り付けてください。

BLOCK DIAGRAM



※1 correspond to 128Mb

%2 correspond to 64Mb
%3 correspond to 128Mb

MD 28CA1-2001072757-1

■ DISASSEMBLY PROCEDURE(分解手順)


Caution: Be sure to attach the removed filament tape just as it was before removal.

注意:分解時に取り外したフィラメントテープは、必ず元通りに取り付けてください。


1. Lower Case Assembly (Time required: About 2 minutes)

- 1-1 Remove the five (5) screws marked [80A], two (2) screws marked [90] and two (2) screws marked [100A]. The lower case assembly can then be removed. (Fig.1)
 - * When installing the lower case assembly, first tighten the screw marked [90] and then the remaining screws. (Fig. 1)
- 1. 下ケース Ass'y (所要時間:約2分)
- 1-1 [80A] のネジ 5 本、[90] のネジ 2 本と [100A] のネ ジ 2 本を外して、下ケース Ass' y を外します。(図 1)
 - ※ 下ケース Ass'y を取り付けるときは、[90] のネジを締めてから他のネジを締めてください。(図 1)

● Bottom view (下から見た図)



● Top view (上から見た図)



2. DMLCD Circuit Board (Time required: About 3 minutes)

- 2-1 Remove the lower case assembly. (See procedure 1.)
- 2-2 Remove the ten (10) screws marked [385]. The DMLCD circuit board can then be removed. (Fig.2)
 - * When installing the DMLCD circuit board, tighten the screws 1 through 10 in numerical order. (Fig. 2)
 - * If the DMLCD circuit board is replaced, execute the "Factory Set" in the test program.

3. LCD (Time required: About 3 minutes)

- 3-1 Remove the lower case assembly. (See procedure 1)
- 3-2 Remove the DMLCD circuit board. (See procedure 2)
- 3-3 Remove the LCD holder and rubber connector. (Fig. 3)
- 3-4 Remove the back-lit assembly. (Fig. 3)
- 3-5 Remove the LCD. (Fig. 3)
 - * When attaching the rubber connector, set the conductive part to face inside. (Fig. 3)
 - * Avoid touching the conductive part of the rubber connector as much as possible. Should foreign matter or dirt adhere, remove such contamination using adhesive tape or the like. Do not wipe off using solvents such as benzene or alcohol. (Fig. 3)

2. DMLCD シート (所要時間:約3分)

- 2-1 下ケース Ass'y を外します。(1 項参照)
- 2-2 [385] のネジ 10 本を外して、DMLCD シートを外 します。(図 2)
 - ※ DMLCDシートを取り付けるときは、1 から 10 の順で ネジを締めてください。(図 2)
 - ※ DMLCDシートを交換した場合は、テストプログラムの Factory Set を実行してください。

3. 液晶ディスプレイ(所要時間:約3分)

- 3-1 下ケース Ass'y を外します。(1 項参照)
- 3-2 DMLCD シートを外します。(2 項参照)
- 3-3 LCD ホルダーとゴムコネクターを外します。 (図 3)
- 3-4 バックライト Ass'y を外します。(図3)
- 3-5 液晶ディスプレイを外します。(図3)
- ※ ゴムコネクターを取り付けるときは導電部を内側にして ください。(図3)
- ※ ゴムコネクターの導電部には極力触れないようにしてください。異物、ごみ等が付着した場合は粘着テープ等で取り除き、ベンゼン・アルコール等の溶剤では拭かないでください。(図3)





Fig.2(図2)



4. PNAM Circuit Board (1/3, 2/3, 3/3)

- 4-1 Remove the lower case assembly. (See procedure 1)
- 4-2 PNAM Circuit Board 3/3
 (Time required: About 2 minutes)
- 4-2-1 Remove the knob from the control panel surface. (Fig. 1, Fig. 4)
- 4-2-2 Remove the three (3) screws marked [380A]. The PNAM circuit board 3/3 can then be removed. (Fig. 2)
- 4-3 PNAM Circuit Board 1/3
 (Time required: About 3 minutes)
- 4-3-1 Remove the PNAM circuit board 3/3. (See procedure 4-2)
- 4-3-2 Remove the sixteen (16) screws marked [380B]. The PNAM circuit board 1/3 can then be removed. (Fig. 2)
- * When installing the PNAM circuit board 1/3, tighten the screws 1, 2 in that order and then the remaining screws. (Fig. 2)
- 4-4 PNAM circuit board (2/3)
 (Time required: About 3 minutes)
- 4-4-1 Remove the thirteen (13) screws marked [380C].
 The PNAM circuit board 2/3 can then be removed.
 (Fig. 2)
 - * When installing the PNAM circuit board 2/3, tighten the screws 1, 2 in that order and then the remaining screws. (Fig. 2)

5. Speaker (Time required: About 2 minutes)

- 5-1 Remove the lower case assembly. (See procedure 1)
- 5-2 Remove the four (4) screws marked [370]. The speaker can then be removed. (Fig. 2)
 - * The right and left speakers can be removed in the same manner.


6. SP Grille (Time required: About 3 minutes each)

- 6-1 Remove the lower case assembly. (See procedure 1)
- 6-2 Align the eight (8) [A]s the groove in the upper case assembly and remove the SP grille. (Fig. 1, Fig. 2)
 - * The right and left SP grilles can be removed in the same manner.

7. Lower Key Bed Assembly (Time required: About 2 minutes each)

- 7-1 Remove the lower case assembly. (See procedure 1)
- 7-2 Remove the two (2) screws marked [80B] and screw marked [100B]. The lower key bed assembly can then be removed. (Fig. 2)

- 4. PNAM シート (1/3、2/3、3/3)
- 4-1 下ケース Ass'y を外します。(1 項参照)
- 4-2 PNAM シート 3/3 (所要時間:約2分)
- **4-2-1** コントロールパネル面から V ツマミを外します。 (図 1、図 4)
- 4-2-2 [380A] のネジ3本を外して、PNAM シート 3/3 を外します。(図2)
- 4-3 PNAM シート 1/3 (所要時間:約3分)
- 4-3-1 PNAM シート 3/3 を外します。(4-2 項参照)
- 4-3-2 [380B] のネジ 16 本を外して、PNAM シート 1/3 を外します。(図 2)
 - ※ PNAM シート 1/3 を取り付けるときは、1、2 の順でネジを締めてから他のネジを締めてください。(図 2)
- 4-4 PNAM シート 2/3 (所要時間:約3分)
- 4-4-1 [380C] のネジ 13 本を外して、PNAM シート 2/3 を外します。(図 2)
 - ※ PNAM シート 2/3 を取り付けるときは、1、2 の順でネジを締めてから他のネジを締めてください。(図 2)



- 5. スピーカ (所要時間) 約2分)
- 5-1 下ケース Ass'y を外します。(1項参照)
- 5-2 [370] のネジ 4 本を外して、スピーカを外します。 (図 2)
 - ※ 左右のスピーカは同じように外せます。

6. SP グリル (所要時間: 各約3分)

- 6-1 下ケース Ass'y を外します。(1 項参照)
- 6-2 [A]の8箇所を、上ケースAss'yの溝と平行にして、 SPグリルを外します。(図1、図2)
 - ※ 左右の SP グリルは同じように外せます。

7. 下ケース鍵盤 Ass'y (所要時間: 各約2分)

- 7-1 下ケース Ass'y を外します。(1 項参照)
- 7-2 [80B] のネジ 2 本と、[100B] のネジ 1 本を外して、 下ケース鍵盤 Ass'y を外します。(図 2)

8. Disassembling Keyboard Assembly (Time required: About 13 minutes)


- 8-1 Remove the lower case assembly. (See procedure 1.)
- 8-2 Remove the lower key bed assembly. (See procedure 7.)
- 8-3 White Keys and Black Keys
- 8-3-1 White and black keys for one octave unit are integrated as a set. There are five sets in total.

 Only the C6 white key, unlike the other keys, is not integrated in a set. (Fig.5)
- 8-3-2 To remove a set, remove the four (4) each screws marked [120A]. The white and black keys in the set can then be removed. (Fig.5)

 When removing, unfasten the two (2) hooks at the back of the black keys upward, and lift the white and black keys while pulling them toward you a little. (Photo 1)
- 8-3-3 To remove the white key C6, remove the screw marked [120B], unhook as described in Procedure 8-3-2, and pull out toward you. (Fig.5)
 - * When all white and black keys were removed, first attach the white and black keys C3 ~ B3 aligning them with the boss, and then attach the remaining white and black keys. (Fig. 5)
- 8-4 Rubber Contact
- 8-4-1 Remove the white and black keys corresponding to the rubber contacts to be removed. (See Fig.5 and Procedure 8-3.)
- 8-4-2 Remove the rubber contacts. (Photo 2, Fig.6)

- 8. 鍵盤 Ass'yの分解(所要時間:約13分)
- 8-1 下ケース Ass'y を外します。(1 項参照)
- 8-2 下ケース鍵盤 Ass' v を外します。(7 項参照)
- 8-3 白鍵、黒鍵
- 8-3-1 白鍵、黒鍵は、左側から 1 オクターブ単位のセットになっていて、全部で 5 セットあります。C6 鍵は白鍵 1 個のみです。(図 5)
- 8-3-2 セットのものは、[120A] のネジ 4 本ずつ外してそれぞれ 1 セット分の白鍵・黒鍵を外します。(図 5) この時、黒鍵の後ろ側にある 2 つのフックを上方向に外し、白鍵・黒鍵を少し手前に引きながら持ち上げます。(写真 1)
- 8-3-3 C6の白鍵は [120B] のネジ1本を外して、8-3-2項 のようにフックを外して手前に引きながら外しま す。(図 5)
 - ※ すべての白鍵・黒鍵を外した場合の組み立ては、最初に C3~B3の白鍵・黒鍵をボスに合わせて組み付けてから、 他の白鍵・黒鍵を組み付けてください。(図 5)
- 8-4 接点ゴム
- 8-4-1 外そうとする接点ゴムに対応した白鍵・黒鍵を外 します。(図 5、8-3 項参照)
- 8-4-2 それぞれの接点ゴムを外します。(写真 2、図 6)

Boss





(鍵盤Ass'y)



RUBBER CONTACT (接点ゴム) Photo 2 (写真2)

● Top view (上から見た図)




Fig.6 (図6)




Fig.7(図7)

8-5 Circuit Board 61L-MK

- 8-5-1 Remove the white and black keys from C1 to B3. (See Fig.5 and Procedure 8-3.)
- 8-5-2 Remove the four (4) screws marked [100C] and eight (8) screws marked [110A]. The circuit board 61L-MK can then be removed. (Fig.6)
 - * When installing the circuit board 61L-MK, tighten the screws 1 through 12 in numerical order as shown in the figure "61L-MK" in Fig.7. (Fig.7)

8-6 Circuit Board 61H-MK

- 8-6-1 Remove the white and black keys from C4 to C6. (See Fig.5 and Procedure 8-3.)
- 8-6-2 Remove the three (3) screws marked [100D] and five (5) screws marked [110B]. The circuit board 61H-MK can then be removed. (Fig.6)
 - * When installing the circuit board 61H-MK, tighten the screws 1 through 8 in numerical order as shown in the figure "61H-MK" in Fig.7. (Fig.7)

- 8-5 シート **61**L
- 8-5-1 C1 ~ B3 の白鍵・黒鍵を外します。 (図 5、8-3 項参照)
- 8-5-2 [100C] のネジ 4 本と [110A] のネジ 8 本を外して、 シート 61L を外します。(図 6)
- ※ シート 61L を取り付けるときは、図7のシート 61L 図の番号1~12の順にネジを締めてください。(図7)
- 8-6 シート **61H**
- 8-6-1 C4 ~ C6 の白鍵・黒鍵を外します。 (図 5、8-3 項参照)
- 8-6-2 [100D] のネジ 3 本と [110B] のネジ 5 本を外して、 シート 61H を外します。(図 6)
 - ※ シート 61H を取り付けるときは、図7のシート 61H 図 の番号1~8の順にネジを締めてください。(図7)

9. How to Remove Spring Terminals

- 9-1 Spring Terminal A and Spring Terminal B
 (Time required: About 4 minutes each)
- 9-1-1 Remove the lower case assembly. (See procedure 1.)
- 9-1-2 Remove the lower key bed assembly. (See procedure 7.)
- 9-1-3 Remove the white and black keys from C1 to B2 (See Fig. 5 and Procedure 8-3.)
- 9-1-4 Remove the BATT connector assembly soldered to the spring terminal A and spring terminal B. (Photo 3)
- 9-1-5 Reverse the lower key bed assembly and remove the battery cover assembly. (Fig.1)
- 9-1-6 Lift the spring terminal A a little and slide it in the upper right direction to remove it. (Fig.8)
- 9-1-7 Remove the hook for the spring terminal B to pull it out from inside. (Fig.8)
- 9-2 Spring Terminal C and Spring Terminal D (Time required: About 1 minute each)
- 9-2-1 Remove the battery cover assembly. (See procedure 9-1-5)
- 9-2-2 Remove the hooks to pull out the spring terminal C and spring terminal D. (Fig.8, Fig.9)

- 9. 接点バネの外し方
- 9-1 接点バネ A、接点バネ B (所要時間: 各約4分)
- 9-1-1 下ケース Ass' v を外します。(1 項参照)
- 9-1-2 下ケース鍵盤 Ass'y を外します。(7項参照)
- 9-1-3 C1~B2の白鍵・黒鍵を外します。 (図 5、8-3 項参照)
- 9-1-4 接点バネ A、接点バネ B に半田付けされている BATT 束線を外します。(写真 3)
- 9-1-5 下ケース鍵盤 Ass'y を裏返して、電池蓋 Ass'y を外します。(図 1)
- 9-1-6 接点バネAは、上に少し引き上げ、右上にスライドして外します。(図8)
- 9-1-7 接点バネBは、フックを外して、内側から引き出 します。(図8)
- 9-2 接点バネ C、接点バネ D (所要時間: 各約1分)
- 9-2-1 電池蓋 Ass' v を外します。(9-1-5 項参照)
- 9-2-2 フックを外して、接点バネ C、接点バネ D を引き 出します。(図 8、図 9)




Fig.8(図8)




Photo 3(写真3)




Fig.9(図9)

■ LSI PIN DESCRIPTION (LSI 端子機能表)

AK4385ET (X6040A01) DAC (Digital to Analog Converter)	5
NT3881DFG-01 (X3148A0R) LCD DRIVER	5
SWL01U (YA876A00) CPU 1	6

• NT3881DFG-01 (X3148A00) LCD DRIVER

DMLCD: IC101

	EMILOS ISI (XOT40XIO) ESP BITTET							
PIN NO.	NAME	1/0	FUNCTION	PIN NO.	NAME	I/O	FUNCTION	
1 2 3 4 5 6 7	S22 S21 S20 S19 S18 S17 S16	0000000		41 42 43 44 45 46 47	DB2 DB3 DB4 DB5 DB6 DB7 C1	I/O I/O I/O I/O I/O I/O	Data interface	
8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	\$15 \$14 \$13 \$12 \$11 \$10 \$9 \$8 \$7 \$6 \$5 \$4 \$3 \$2 \$1	000000000000000	Segment signal output for LCD driving	48 49 50 51 52 53 54 55 56 57 58 59 60 61 62	C2 C3 C4 C5 C6 C7 C8 C9 C10 C11 C12 C13 C14 C15 C16	0000000000000000	Common signal output for LCD driving	
22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40	Vss OSC1 OSC2 V1 V2 V3 V4 V5 CLK1 CLK2 Vdd M D RS R/W E DB0 DB1	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Ground Oscillator Oscillator Power supply Data latch clock Data shift clock Power supply (+5 V) Altamated signal for LCD driver outout Display data interface Read/write Enable Data interface Data interface Data interface	62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80	\$39 \$38 \$37 \$36 \$35 \$34 \$33 \$32 \$31 \$30 \$29 \$28 \$27 \$26 \$25 \$24 \$23	000000000000000000000000000000000000000	Segment signal output for LCD driving	

• **AK4385ET** (X6040A01) **DAC** (Digital to Analog Converter)

DMLCD: IC104

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
1	MCLK	- 1	Master Clock	9	AOUTR-	0	Rch Analog out(-)
2	BICK	1	Audio Serial Data Clock	10	AOUTR+	0	Rch Analog out(+)
3	SDTI	- 1	Audio Serial Date Input	11	AOUTL-	0	Lch Analog out(-)
4	LRCK	- 1	L/R Clock	12	AOUTL+	0	Lch Analog out(+)
5	PDN	1	Power Down mode	13	Vss	-	Ground
6	CSN	1	Chip Select	14	VDD	-	Power Supply
7	CCLK	- 1	Control Data Input	15	DZFR	0	Rch Data Zero Input Detect
8	CDTI	- 1	Control Data Input	16	DZFL	0	Lch Data Zero Input Detect

• SWL01U (YA876A00) CPU

DMLCD: IC102

PIN	NARAE	1/0	ELINCTION	PIN	NAME	1/0	FUNCTION				
NO.	NAME	I/O	FUNCTION	NO.	NAME	I/O		FUNCTION			
1 2	NC NC	-	Connection to the GND	89 90	NC NC	-	}	Connection to the GND			
3	EA3/PD3/KYN24	1	3	91	MD03	I/O	$1 \leq$				
4 5	EA2/PD2/KYN23 EA1/PD1/KYN22		ON/OFF signal from the keyboard	92	MD11 MD04	I/O I/O					
	EA0/PD0/KYN21	i		94	MD12	1/0					
7	ED0/PC0/KYN11	1/0		95	MD05	I/O		External memory data bus			
8 9	ED1/PC1/KYN12 ED2/PC2/KYN13	I/O I/O		96	MD13 MD06	I/O I/O					
10	ED3/PC3/KYN14	I/O	> Key selection signal to the keyboard	98	MD14	I/O					
11 12	ED4/PC4/KYN15 ED5/PC5/KYN16	I/O I/O	Noy colocion dignario and Royscard	99	MD07 MD15	I/O I/O					
13	ED6/PC6/KYB05	1/0		101	Vss	-	_	Digital Core ground			
14	ED7/PC7/KYB06 PROTN	I/O I	Determines if the product is a proteture	102 103	CS50RDN/PE4/RCLK MA17	0		Priority of setup) PE4 > RCLK(SDRAM) > CS50RDN			
15 16	BISTMD	¦	Determines if the product is a prototype Memory BIST mode (1: BIST mode)	103	MA23	0					
17	BISTCLK	!	Memory BIST clock	105	MA16	0					
18 19	PLLBPN TESTN	I	PLL bypass mode (0: PLL bypass) Test mode	106	MA15 MA14	0	}	External memory address			
20	Vss	-	Digital Core ground	108	MA13	0					
21 22	XI XO	I 0	Crystal oscillator input (33.8688 MHz) Crystal oscillator output	109	MA12 MA11	0					
23	VDD	-	Digital Core power supply	111	VDD	-		Digital Core power supply			
24	Vss	-	Digital Core ground	112	IOVDD	I/O		I/O power supply			
25 26	IOV _{DD} TRSTN	I/O 	I/O power supply JTAG I/F reset	113	MA10 MA09	0					
27	TMS	i	JTAG I/F mode	115	MA20	0					
28 29	TCK TDI		JTAG I/F clock JTAG I/F input	116 117	MA21/PF1 MA22/PF2	0					
30	TDO	i	JTAG I/F output	118	MA19	ő					
31	VDD	-	Digital Core power supply	119	MA18	0		Futowal maman, adduses			
32 33	PLLV _{DD} Vss	-	Digital PLL power supply (common with Core power supply inside) Digital Core ground	120 121	MA08 MA07	0		External memory address			
34	PLLVss	-	Digital PLL ground (common with Core ground inside)	122	MA06	0					
35 36	WCLK/SYO PFO	0	Word clock (1 Fs = 44.1 kHz) Output-only port	123 124	MA05 MA04	0					
37	SDO1	ő	Audio output data (with EQ & compressor)	125	MA03	ő					
38 39	SDO0 BCLK	0	(SWL01 equivalent output data)/Selection signal to the keyboard Bit clock (64Fs)	126 127	MA02 MA00	0					
40	SYSCLK/PG3	0	System clock (256Fs/384Fs/768Fs)	128	CS1N/PG1	0		Chip select for area 3			
41	SDI/PH3	Ī	Serial audio input data	129	Vss	-		Digital Core ground			
42 43	Vss IRQON/PHO	- i	Digital Core ground Interrupt input	130	ICN Vss	I		Reset Digital Core ground			
44	NC	:	oropt in par	132	NC	-					
45 46	NC NC	-	Connection to the GND	133	NC NC	-	}	Connection to the GND			
47	NC]	J	135	PA0	I/O	15				
48 49	TXD0/PG4 RXD0/PH4	O	Serial port I/F Serial port I/F	136	PA1 PA2	I/O I/O					
50	TXD1/PG2	0	Serial port I/F	138	PA3	1/0					
51	RXD1/PH1	!	Serial port I/F	139	PA4	1/0					
52 53	SCLK1/PH2 UCTL		Serial port I/F Fixed L when USB is in use/Fixed H when not in use	140 141	PA5 PA6	I/O I/O					
54	VDD	-	Digital Core power supply	142	PA7	I/O		Universal I/O port			
55 56	Vss AV _{DD}	-	Digital Core ground Analog power supply	143 144	PB0 PB1	I/O I/O		ominoral no port			
57	AVREF	1	ADC reference	145	PB2	I/O					
58 59	AN0 AN1			146 147	PB3 PB4	I/O I/O					
60	AN2	i	> ADC input	148	PB5	1/0					
61 62	AN3		ADC ground reference	149 150	PB6	1/0					
63	AGNDREF AVss		ADC ground reference Analog ground	150	PB7 IOV _{DD}	I/O I/O		I/O power supply			
64	USBVDD	-	USB I/O power supply 1.8v (Pullup when not in use)	152	Vss	-		Digital Core ground			
65 66	FUNC_DM FUNC_DP	I/O I/O	USB data - USB data +	153 154	VDD WRN/PF5/WEN	0		Digital Core power supply Priority of setup) PF5 > WEN(SDRAM) > WRN			
67	USBVss	-	USB I/O ground	155	UBN/PF7/UDQM	0		Priority of setup) PF7 > UDQM(SDRAM) > UBN			
68 69	USBIOV _{DD} Vss	-	USB I/O power supply 3.3v (Pullup when not in use) Digital Core ground	156 157	LBN/PF6/LDQM CS2N/PE0/KYB07	0		Priority of setup) PF6 > LDQM(SDRAM) > LBN Chip select for area 4			
70	VDD	-	Digital Core power supply	158	CS3N/PE1/KYB08			Chip select for area 5			
71 72	XI_UCLK XO UCLK	ı	Crystal oscillator input (48 MHz) Crystal oscillator output	159 160	CS4N/PE2	0		Chip select for area 6			
73	Vss	0	Crystal oscillator output Digital Core ground	161	CS5N/PE3/KYB09 CS51WRN/PE5/KYB12	0	7	Chip select for area 7			
74	IOVdd	I/O	I/O power supply	162	CS52WRN/PE6/KYB13	0	}	For luminescent keyboard			
75 76	VBUS PULLUPE	I 0	USB Vbus USB Pullup enable	163 164	CS53WRN/PE7 PF3	0	ر ا	Output-only port			
77	CS0N/PG0	0	Chip select for area 2	165	PJ5	0	1				
78 79	RDN/PF4 MA01	0	External memory read signal External memory address	166 167	PJ4/KYB11 PJ3/KYB01	0					
80	MD00	1/0	Literial memory address	168	PJ2/KYB04	0	}	Used as key selection signal to the keyboard			
81	MD08	I/O		169	PJ1/KYB03	0					
82 83	MD01 MD09	I/O I/O	External memory data bus	170 171	PJ0/KYB02 Vss	0		Digital Core ground			
84	MD02	I/O		172	ECSN	ļ.		Chip select input from external CPU			
85 86	MD10 NC	I/O -	7	173 174	EWRN/PD5/KYN26 ERDN/PD4/KYN25			Write enable input from external CPU Read enable input from external CPU			
87	NC	-	Connection to the GND	175	NC	-	1	Connection to the GND			
88	NC	-	<u> </u>	176	NC	-	5	Connection to the Civi			


■ CIRCUIT BOARDS(シート基板図)

DMLCD Circuit Board (YC994C0)	19
PNAM 1/3 Circuit Board (YD033C0)	18
PNAM 2/3 Circuit Board (YD033C0)	17
PNAM 3/3 Circuit Board (YD033C0)	18
61H-MK Circuit Board (X2335D0)	20
61L-MK Circuit Board (X2336C0)	20

Note: See parts list for details of circuit board component parts.


注: シートの部品詳細はパーツリストをご参照ください。

PNAM 2/3 Circuit Board




Component side (部品側)

PNAM 1/3 Circuit Board



Component side (部品側)


PNAM 3/3 Circuit Board




Component side (部品側)


DMLCD Circuit Board


Scale: 90/100






• 61H-MK Circuit Board





Component side (部品側)

• 61L-MK Circuit Board



Component side (部品側)

■ TEST PROGRAM

* If the test number 52 "Factory Set" is executed, the data already set will be lost.

1 Preparations


- 1) Use an AC adaptor PA-3C, PA-130 or PA-130A.
- 2) Measuring device: Frequency counter, which can detect thousandth value or more, Level meter (with JIS-C filter), Oscilloscope Note: Use a stereo plug and connect a load resistor of 33 Ω to the [PHONES/OUTPUT] jack for measurement unless otherwise specified. Input impedance of the measuring device should be 1 M Ω or more.
- 3) Jig: Foot switch (FC-4 or FC-5), MIDI cable
- 4) Controller settings

MASTER VOLUME: MAX PEDAL: OFF WIDE: OFF

Others : Initial setting when the power is turned on

2 Starting up the Test Program

While holding down the keys [C#2], [F2] and [G#2] simultaneously, press the [STANDBY / ON] switch.



3 Test procedure

- 1) When the test program is started, "TEST" will be displayed on the LCD.
- 2) Press the [Tenkey -] or [Tenkey +] button to select a test program item.
- 3) Press the [START/STOP] button to execute the test.

If the result is OK or test item is completed, press the [START/STOP] button again to return to the item selection display.

Press the [Tenkey –] or [Tenkey +] button to select the next test item.

A cursor ("_") is shown below the first character of the item for which the test results are OK.

If the result is NG, press the [DEMO/BGM] button or the lowest key (white key C1) to return to the item selection display.

4 Test Program List (dBu=dBm)

TEST No	LCD display		Test descriptions, judging conditions, etc.						
1	001: Version	Displays ve	Displays version of the ROM.						
		Using the to	enkeys, each data version car	be displayed as follows.					
		[Tenkey 1]	Main Program Version	"*** Main"					
		[Tenkey 2]	Boot Program Version	"*** Boot"					
		[Tenkey 3]	Style Data Version	"*** Style"					
		[Tenkey 4]	Song Data Version	"*** Song"					
		[Tenkey 5]	Voice Parameter Version	"*** Param"					
		[Tenkey 6]	Wave Data Version	"*** Wave"	*** : Version				
2	002: Mem1 All	Checks the	ROM, RAM and FROM cor	nnected to the CPU bus.					
		Make sure t	that " Mem1 OK " is displaye	ed on the LCD.					
		* If the te	st result is OK, the tests	"003: Rom Chk1", "004: Ra	m Chk1" and "005:				
		FRom C	hk1" can be skipped.						
3	003: Rom Chk1	Checks the	ROM connected to the CPU	bus.					
		Make sure t	Make sure that "Rom OK" is displayed on the LCD.						
4	004: Ram Chk1	Checks the	Checks the RAM connected to the CPU bus.						
		Make sure	Make sure that "Ram OK" is displayed on the LCD.						
5	005: FRomChk1	Checks the	FROM connected to the CPI	J bus.					
		Make sure	that " FRom OK " is displaye	ed on the LCD.					

TEST No	LCD display	Test descriptions, judging conditions, etc.
8	008:TG1 Chk	Plays each key automatically in the order of scale (auto-scaling). (32 notes from C2 to G4 will be played.)
		Make sure that there is no abnormal sounds or noise. When the auto-scaling is finished, " TG1 End "
		will be shown. Press a key to play a sound. (Single note, the key pressed first will be played)
9	009: Pit Chk	Checks pitch accuracy.
		Connect the frequency counter to the [PHONES/OUTPUT] jack. (Either L or R)
		Make sure that the correct signal is output. $(441.0 \text{ Hz} \pm 0.2 \text{ Hz})$
		Amount of volume decay
		Connect the level meter (with JIS-C fi lter) to the L/R of the [PHONES/OUTPUT] jack. (33 Ω load)
		Turn the [MASTER VOLUME] to the minimum and measre the amount of volume decay.
		· PHONES L, R: -70 dBu or less
10	010: Output R	Connect the level meter (with JIS-C filter) to the L/R of the [PHONES/OUTPUT] jack.
		$(33 \Omega load)$
		Set the [MASTER VOLUME] to the maximum level and check the output level.
		· PHONES R: −1.0 dBu ± 2 dB · PHONES L: −45.0 dBu or less
11	011: Output L	Connect the level meter (with JIS-C filter) to the L/R of the [PHONES/OUTPUT] jack.
		$(33 \Omega \text{ load})$
		Set the [MASTER VOLUME] to the maximum level and check the output level.
		PHONES L: -1.0 dBu ± 2 dB PHONES R: -45.0 dBu or less
21	021: SW Chk	Checks the switches on the panel. Press the switches as shown in the LCD. When a switch is
		pressed, a sound is played at the prescribed pitch. (Refer to the Switch test item list on the next
		page.)
		Make sure that " SW OK " is displayed on the LCD when all the switches are pressed as indicated. To cancel the running test, press the [DEMO/BGM] button or the lowest key (white key C1) to return to the
		item selection display.
25	025: LCD On	Make sure that all the dots on the LCD are turned on.
26	026: LCD Off	Make sure that all the dots on the LCD are turned off.
29	029: PD1 Chk	Connect a footswitch (FC-4 or FC-5) to the [SUSTAIN] jack. Check that C3 sound is played when the [Start/Stop] button is pressed with the pedal depressed and
		that C4 sound is played when the pedal is released. Depress the pedal again and the sound will be
		stopped.
		Make sure that " PD1 OK " is displayed on the LCD.
47	047: Rom Chk2	Checks the ROM connected to the CPU bus.
"	O47.110III OIIILE	Make sure that "Rom OK" is displayed on the LCD.
		It will take about 12 seconds for the check.
48	048: Ram Chk2	Checks the RAM connected to the CPU bus.
"		Make sure that "Ram OK" is displayed on the LCD.
49	049: FRomChk2	Checks the FROM connected to the CPU bus.
		Make sure that " FRom OK " is displayed on the LCD.
		It will take about 95 seconds for the check.
52	052: Factory	Initializes the entire backup area to reset to the factory default.
	,	" Fact " is displayed on the LCD during the test.
		"Fact End" is displayed on the LCD when the test is finished.
53	053: TestExit	This will leave the test program and change to the play mode.
ეა	USS. TESTEXIT	This will leave the test program and change to the play mode.

Other Tests

Popping Noise Check

Connect the oscilloscope to the L/R of the [PHONES/OUTPUT] jack and turn on and then off the [STANDBY/ON] switch. Make sure that popping noise level is 1.0 Vp-p or less, and that no abnormal sound or popping noise is output from the speakers.

Noise Level Check

Connect the level meter (with JIS-C filter) to the L/R of the [PHONES/OUTPUT] jack. (33 Ω load) Set the [MASTER VOLUME] to the maximum level and check the noise level.

· PHONES L, R: -75 dBu or less

Switch test item list

Turn	SW Name	LCD Display	Note Number
1	1 LISTENING 2 TIMING 3 WAITING	Lesson	C2
2	KEYS TO SUCCESS	Keys	C#2
3	PHRASE REPEAT	P Rep	D2
4	METRONOME	Metro	D#2
5	TEMPO/TAP	Temp/TAP	E2
6	PART L	Left	F2
7	PART R	Right	F#2
8	SONG	Song	G2
9	VOICE	Voice	G#2
10	STYLE	Style	A2
11	TENKEY 1	Tenkey 1	A#2
12	TENKEY 2	Tenkey 2	B2
13	TENKEY 3	Tenkey 3	C3
14	TENKEY 4	Tenkey 4	C#3
15	TENKEY 5	Tenkey 5	D3
16	TENKEY 6	Tenkey 6	D#3
17	TENKEY 7	Tenkey 7	E3
18	TENKEY 8	Tenkey 8	F3
19	TENKEY 9	Tenkey 9	F#3
20	TENKEY -	Tenkey –	G3
21	TENKEY 0	Tenkey 0	G#3
22	TENKEY +	Tenkey +	A3
23	FUNCTION	Function	A#3
24	DEMO/BGM	Demo	B3
25	A-B REPEAT	AB Rep	C4
26	REW	Rew	C#4
27	FF	FF	D4
28	PAUSE	Pause	D#4
29	START/STOP	StartStp	E4
30	REC	Record	F4
31	PORTABLE GRAND	GP	F#4
32	MUSIC DATABASE	MDB	G4
33	ULTRA-WIDE STEREO	WIDE	G#4
34	SPLIT	Split	A4
35	DUAL	Dual	A#4
36	HARMONY	Harmony	B4
37	TOUCH	Touch	C5

■テストプログラム

※テストナンバー 52 の Factory Set を実行すると、設定したデータが失われます。

1 準備


- 1) AC アダプターは PA-3C、PA-130 または PA-130A を使用します。
- 2) 測定器 : 周波数カウンター(小数点以下 3 桁以上測定可能なもの)、レベルメーター (JIS-C フィルター使用)、オシロスコープ
 - 注)特に指示のない限りステレオプラグを用い、[ヘッドフォン/外部出力]端子に 33 Ω の負荷抵抗を接続して測定します。測定器の入力インピーダンスは 1 M Ω 以上であること。
- 3) 治具: フットスイッチ (FC-4 または FC-5)、MIDI ケーブル
- 4) コントロール状態

[全体音量] コントロール : 最大 PEDAL : OFF WIDE : OFF

その他 : 電源 ON 時のデフォルト状態

2 テストプログラムの起動

[C#2]、[F2]、[G#2] の鍵盤を同時に押しながら、[スタンバイ / オン] スイッチを押します。





3 テストの進め方

- 1) テストプログラムが起動されると、LCD に "TEST" が表示されます。
- 2) [テンキー -] または[テンキー +] ボタンを押して、テストプログラムの項目を選択します。
- 3) [スタート/ストップ] ボタンを押してテストを実行します。

結果が OK、またはテスト項目終了の場合は、再度 [スタート / ストップ] ボタンを押して項目選択表示に戻ります。 [テンキー -] または [テンキー +] ボタンを押して、次のテスト項目を選択します。 テスト結果が OK だった項目名の一字目下にカーソル ("__ ") が表示されます。

結果が NG の場合は、[デモ / BGM] ボタンまたは鍵盤の最低音(白鍵 C1) を押して、項目選択画面に戻ります。

4 テスト一覧 (dBu=dBm)

テストNo	LCD 表示	テスト内容及び判定条件など				
1	001: Version	ROM のバージョンを表示します。	П			
		テンキーを押すと以下のデータ毎のバージョンを表示します。				
		[テンキー1] Main Program Version "*** Main"				
		[テンキー 2] Boot Program Version "*** Boot"				
		[テンキー 3] Style Data Version "*** Style"				
		[テンキー 4] Song Data Version "*** Song"				
		[テンキー 5] Voice Parameter Version "*** Param"				
		[テンキー 6] Wave Data Version "*** Wave" ***: Version	n			
2	002: Mem1 All	CPU のバスに接続されている ROM、RAM、FROM をチェックします。				
		LCD に "Mem1 OK" が表示されることを確認します。				
		※ テスト結果が OK の場合は、"003: Rom Chk1"、"004: Ram Chk1"、"005: FRom Chk1"				
		のテストを省略できます。				
3	003: Rom Chk1	CPU のバスに接続されている ROM をチェックします。				
		LCD に "Rom OK" が表示されることを確認します。				
4	004: Ram Chk1	CPU のバスに接続されている RAM をチェックします。				
		LCD に "Ram OK" が表示されることを確認します。				
5	005: FRomChk1	CPU のバスに接続されている FROM をチェックします。				
		LCD に "FRom OK" が表示されることを確認します。				

テストNo	LCD 表示	テスト内容及び判定条件など				
8	008: TG1 Chk	鍵盤を自動的にスケーリングします。 (発音鍵域は、C2 から G4 までの 32 音です。)				
		異音、ノイズの無いことを確認します。オートスケーリングが終了すると、"TG1 End"				
		と表示され鍵盤を弾くことで発音します。(単音、先着優先)				
9	009: Pit Chk	ピッチ精度のチェック。				
		[ヘッドフォン / 外部出力] 端子に周波数カウンターを接続します。(L か R のどちらか)				
		正しい信号が出力されていることを確認します。(441.0 Hz ± 0.2 Hz)				
		ボリューム減衰値				
		[ヘッドフォン / 外部出力] 端子の L, R にレベルメーター(JIS-C フィルター使用)を接続				
		します。(33 Ω負荷)				
		[全体音量]コントロールを最小にして、ボリューム減衰値を測定します。				
		· PHONES L, R: –70.0 dBu 以下				
10	010: Output R	[ヘッドフォン / 外部出力] 端子の L, R にレベルメーター(JIS-C フィルター使用)を接続				
		します。(33 Ω負荷)				
		[全体音量] コントロールを最大にして、出力レベルをチェックします。				
		・PHONES R: −1.0 dBu ± 2 dB ・PHONES L: −45.0 dBu 以下				
11	011: Output L	[ヘッドフォン / 外部出力] 端子の L, R にレベルメーター(JIS-C フィルター使用)を接続				
		します。(33 Ω負荷)				
		[全体音量] コントロールを最大にして、出力レベルをチェックします。				
	004 004 011	・PHONES L: -1.0 dBu ± 2 dB ・PHONES R: -45.0 dBu 以下				
21	021: SW Chk	パネル上のスイッチをチェックします。LCD に表示されたスイッチを指示通りに押しま イッチを押すと決められた音程で発音します。(次頁の SW テスト項目リスト参照)				
		全部のスイッチを指示通りに押したとき、LCD に "SW OK" が表示されることを確認します。				
		途中で中止する場合は、「デモ / BGM] ボタンまたは鍵盤の最低音(白鍵:C1)を押すと選				
		画面に戻ります。				
25	025: LCD On	LCDのすべてのドットが点灯することを確認します。				
26	026: LCD Off	LCDのすべてのドットが消えることを確認します。				
29	029: PD1 Chk	[サステイン] 端子にフットスイッチ (FC-4 または FC-5) を接続します。				
23	OZS. I DI OIIK	ペダルを踏んだ状態で [スタート / ストップ] ボタンを押すと C3 を発音し、ペダルを離				
		すと C4 を発音することを確認します。再度ペダルを踏むと消音します。				
		LCDに"PD1 OK"と表示されることを確認します。				
47	047: Rom Chk2	CPU のバスに接続されている ROM をチェックします。				
		LCD に "Rom OK" が表示されることを確認します。				
		検査には約12秒かかります。				
48	048: Ram Chk2	CPU のバスに接続されている RAM をチェックします。				
		LCD に "Ram OK" が表示されることを確認します。				
49	049: FRomChk2	CPU のバスに接続されている FROM をチェックします。				
		LCD に "FRom OK" が表示されることを確認します。				
		検査には約95秒かかります。				
52	052: Factory	すべてのバックアップ領域を初期化して工場出荷状態にします。				
		テスト中 LCD に "Fact" が表示されます。				
		テストが終わると、LCD に "Fact End"が表示されます。				
53	053: TestExit	実行すると、テストプログラムから抜けて、プレイモードになります。				

● その他の検査

ポップノイズチェック

[ヘッドフォン/外部出力]端子のL,Rにオシロスコープを接続して、[スタンバイ/オン]スイッチをオン、オフします。 ポップノイズが 1.0 Vp-p 以下であることとスピーカーから異音やポップ音が出ないことを確認します。

ノイズレベルチェック

[ヘッドフォン / 外部出力] 端子の L, R にレベルメーター(JIS-C フィルター使用)を接続します。(33 Ω 負荷) [全体音量] コントロールを最大にして、ノイズレベルをチェックします。

· PHONES L, R: -75 dBu 以下

SW テスト項目リスト

順番	SW 名	ディスプレイ表示	ノート番号
1	1 お手本 2タイミング 3マイペース	Lesson	C2
2	ソングマスター	Keys	C#2
3	フレーズ練習	P Rep	D2
4	メトロノーム	Metro	D#2
5	テンポ / タップ	Temp/TAP	E2
6	左手	Left	F2
7	右手	Right	F#2
8	ソング	Song	G2
9	楽器	Voice	G#2
10	スタイル	Style	A2
11	テンキー 1	Tenkey 1	A#2
12	テンキー 2	Tenkey 2	B2
13	テンキー3	Tenkey 3	C3
14	テンキー 4	Tenkey 4	C#3
15	テンキー 5	Tenkey 5	D3
16	テンキー 6	Tenkey 6	D#3
17	テンキー 7	Tenkey 7	E3
18	テンキー8	Tenkey 8	F3
19	テンキー 9	Tenkey 9	F#3
20	テンキー –	Tenkey –	G3
21	テンキー 0	Tenkey 0	G#3
22	テンキー+	Tenkey +	А3
23	機能	Function	A#3
24	デモ / BGM	Demo	В3
25	A-B リピート	AB Rep	C4
26	巻戻し	Rew	C#4
27	早送り	FF	D4
28	一時停止	Pause	D#4
29	スタート / ストップ	StartStp	E4
30	録音	Record	F4
31	グランドピアノ	GP	F#4
32	ミュージックデータベース	MDB	G4
33	ウルトラワイドステレオ	WIDE	G#4
34	スプリット	Split	A4
35	デュアル	Dual	A#4
36	ハーモニー	Harmony	B4
37	タッチ	Touch	C5

BACKUP

The following settings are always backed up, and are maintained even when the power is turned off. If you want to initialize the settings, use the Initialize operation "Initialization" as explained below.

Backup parameters

- User Songs
- · Style Number 107
- · Touch Response on/off
- · Passing status of Song and Step
- FUNCTION Settings: Tuning, Split Point, Touch Sensitivity, Style Volume, Song Volume, Metronome Volume, Your Tempo, Demo Group, Demo Play Mode, Demo Cancel, Master EQ type, Panel Sustain, Auto Power Off

■ INITIALIZATION

This function erases all backup data in the instrument's flash memory and restores the initial default settings. The following initialization procedures are provided.

Initialization

To clear data backed up to the internal flash memory turn the power on by pressing the [🖒] (Standby/On) switch while holding the highest white key on the keyboard. The backed up data will be erased and the default values restored.





When you execute the Initialization, backup parameters will be cleared.

Initialization does not delete the files transferred from the computer. If you want to delete the files, see "Deleting Files" below.

Deleting Files

To clear song and style files that have been transferred to the internal flash memory from a computer, turn the power on by pressing the [b] (Standby/On) switch while simultaneously holding the highest white key on the keyboard and the three highest black keys.





When you delete the files, Song data and Style data you have purchased and downloaded will also be cleared. Make sure to save your important data by transferring to a computer using Musicsoft Downloader. (Refer to page 31)

■バックアップ

以下のデータは自動的にバックアップされるため、電源を切ってもデータは消えません。設定を初期設定(工場出荷時の状態)に戻すときは、下記の「初期化」を行います。

● バックアップされる内容

- ・ユーザーソング
- ・スタイル番号 107 に登録されたスタイルファイル
- ・タッチレスポンス オン/オフ
- ・ソングとステップの合格記録
- ・機能設定の各設定:チューニング、スプリットポイント、タッチ感度、

スタイル音量、ソング音量、メトロノーム音量、 ユアテンポ、デモグループ、デモ再生モード、

デモキャンセル、マスターEQタイプ、パネルサステイン、

オートパワーオフ

■初期化

楽器の設定を初期設定(工場出荷時の状態)に戻すことができます。尚、初期化すると、すべてのデータが消去されますので、大切なデータは事前にコンピューターに保存する必要があります。

● 初期化の方法

鍵盤の最高音(白鍵)を押しながら[0](スタンバイ/オン)スイッチを押して電源を入れると、楽器は初期設定に戻ります。





初期化するとユーザーソングと、スタイル番号 107 番の登録も消去されます。

コンピューターから転送されたファイルだけは初期化では消去できませんので、「ファイルの削除」を行ってください。

● ファイルの削除

コンピューターから本体内部メモリーに転送したソングデータやスタイルファイルをクリアしたいときは、鍵盤の最高音(白鍵)と一番高い黒鍵3つを同時に押しながら [**ウ**](スタンバイ/オン)スイッチを押して電源を入れると、上記のデータは消去されます。






「ファイルの削除」を行うと、購入した有料のソングデータやスタイルファイルも消去されます。消去したくないデータは、必要に応じて Musicsoft Downloader でコンピューターに保存します。(33ページ参照)

CONNECTING A PERSONAL COMPUTER

- Turn off the power of the instrument before connecting a USB cable.
- Turn on the power of the computer.

Quit any open application software on the computer.

? Connect the instrument and the computer via a USB cable.



Turn on the power of the instrument.

When you connect the instrument to a computer for the first time, the driver is installed automatically.

Operating System (OS)

Windows XP (SP3 or later)/Windows Vista *Only 32-bit, Windows 7, Mac OS X Version 10.5.0-10.6.x

When data communication is unstable or some problem occurs even though you've executed the above instructions, download the Yamaha Standard USBMIDI driver from the following URL then install it to your computer. For instructions on installation, refer to the Install Guide included in the package file.

http://download.yamaha.com/

For details about OS for Yamaha Standard USB-MIDI driver, visit the URL above.

■ Precautions when using the USB terminal


When connecting the computer to the USB terminal, make sure to observe the following points. Failing to do so risks freezing the computer and corrupting or losing the data. If the computer or the instrument freezes, restart the application software or the computer OS, or turn the power to the instrument off then on again.



- Use an AB type USB cable of less than about 3 meters. USB 3.0 cables cannot be used.
- Before connecting the computer to the USB terminal, exit from any power-saving mode of the computer (such as suspend, sleep, standby).
- Before turning on the power to the instrument, connect the computer to the USB terminal.
- Execute the following before turning the power to the instrument on/off or plugging/unplugging the USB cable to/from the USB terminal.
 - · Quit any open application software on the computer.
 - · Make sure that data is not being transmitted from the instrument. (Data is transmitted only by playing notes on the keyboard or playing back a song.)
- While the computer is connected to the instrument, you should wait for six seconds or more between these operations: (1) when turning the power of the instrument off then on again, or (2) when alternately connecting/disconnecting the USB cable.

■コンピューターと接続する

- 1 USB ケーブルを接続する前に、楽器の電源を切ります。
- **2** コンピューターを起動させます。 コンピューター上のアプリケーションは、起動させないでください。
- 3 楽器とコンピューターを USB ケーブルで接続します。



▲ 楽器の電源を入れます。

お使いのコンピューターに USB-MIDI ドライバーが自動でインストールされます。

対応 OS: Windows XP (SP3 以上) / Vista *32 ビットのみ対応、

Windows 7, Mac OS X Version $10.5.0 \sim 10.6.x$

通常はこの状態で通信できますが、動作が不安定だったり、不具合が発生したりする場合は、ヤマハ標準の USB-MIDI ドライバーを下記の URL からインストールして使用します。インストール方法は、ダウンロードファイルに付属されているインストールガイドを参照してください。

http://www.yamaha.co.jp/download/usb midi/

ヤマハ標準の USB-MIDI ドライバーの対応 OS については、上記 URL で確認します。

■ USB 端子ご使用時の注意

USB 端子でコンピューターと接続するときは、以下のことを行います。以下のことを行わないと、コンピューターや本体が停止(ハングアップ)して、データが壊れたり、失われたりするおそれがあります。コンピューターや本体が停止したときは、アプリケーションやコンピューターを再起動したり、本体の電源を入れなおします。



- USB ケーブルは、AB タイプのものを使用します。また、3 メートル以下のケーブルをご使用ください。 (USB3.0 ケーブルは使用できません)
- USB 端子でコンピューターと接続する前に、コンピューターの省電力(サスペンド / スリープ / スタンバイ / 休止)モードを解除します。
- 本体の電源を入れる前に、USB 端子とコンピューターを接続します。
- 本体の電源オン / オフや USB ケーブルの抜き差しをする前に、以下のことを行います。
- ・すべてのアプリケーションを終了させる。
- ・本体から演奏データが送信されていないか確認する。(鍵盤を演奏したりソングを再生させると、本体からデータが送信されます。)
- 本体の電源オン / オフや USB ケーブルの抜き差しは、6 秒以上間隔を空けて行います。

TRANSFERRING DATA BETWEEN THE PSR-E333/YPT-330 and a COMPUTER

This instrument includes 102 preset Songs and 106 Styles, but you can load other Songs and Styles from your computer and use them in the same way as the preset Songs and Styles as long as the loaded Song is SMF format 0* or the loaded Style is SFF (Style File Format). Loaded Song data will be stored to Song numbers beginning with 108 and one of the loaded Style/s can be registered as the 107th Style. In order to perform the operations described in this section you will need to use a computer connected to the Internet to download the free Musicsoft Downloader application.

* The SMF (Standard MIDI File) format is one of the most common and widely compatible sequence formats used for storing sequence data. Most commercially available MIDI sequence data is provided in SMF Format 0.

Installing Musicsoft Downloader

You can download the "Musicsoft Downloader" application from the following website. Make sure that your computer has an Internet connection.

http://download.yamaha.com/



Please use Musicsoft Downloader version 5.6.1 or later.

Please visit the URL above to get the information on the computer system requirements for Musicsoft Downloader.

Transferring Data by using the Musicsoft Downloader

You can transmit Song files and Style Files from your computer to the Flash Memory on your instrument by Musicsoft Downloader. You can also transfer backup data other than the "Passing status of Song and Step" to a computer as a backup file. For Musicsoft Downloader operating instructions see the Help menu: launch the Musicsoft Downloader application and click "Help."

Data that can be loaded to this instrument from a computer

• Songs : 256 Songs max (Song numbers 108–)

Data : Approx. 1.7MBData Format: SMF Format 0 and 1File : 11PK3.BUP (Backup file)

***.mid (MIDI Song)

***.sty (Style File)

Musicsoft Downloader Operations

Move the file from the computer to "Flash Memory" under "Electronic Musical Instruments."



- The Musicsoft Downloader application may not be able to access the instrument in the following cases:
- · During Style playback
- · During Song playback
- Close the window to exit from the Musicsoft Downloader and re-enable control of the instrument.



- Use the power adaptor when transferring data.
 The data can be corrupted if the batteries fail during the transfer.
- Never turn the power off and never plug/unplug the AC power adaptor during data transmission. Not only
 will the data fail to be transferred and saved, but operation of the flash memory may become unstable and
 its contents may disappear completely when the power is turned on or off.

Data that can be transferred to a computer from this instrument

- Backup file (11PK3.BUP: backup data containing five User Songs)
- · Songs transferred from a computer

Musicsoft Downloader Operations

Move the file from "System Drive" under "Electronic Musical Instruments" to the computer.

Erasing Transferred Song Data from Internal Memory

To erase all Songs transferred from the computer, use the "Deleting Files" function on page 27. To erase specific Songs transferred from the computer, use the Delete function on Musicsoft Downloader.



- Preset Song data cannot be transmitted from the PSR-E333/YPT-330.
- "Passing status of Song and Step" cannot be transferred from the PSR-E333/YPT-330 as a "backup file."



- The backup data, including the five User Songs is transmitted/received as a single file. As a result, all backup data (including the five Songs) will be overwritten every time you transmit or receive. Keep this in mind when transferring data.
- Do not rename the backup file on the computer. If you do so, it will not be recognized when transferred to the instrument.

■ PSR-E333 とコンピューターの間でデータを送受信する

この楽器はソング (1 ~ 102) を内蔵していますが、そのほかに 108番以降のソング番号に、コンピューターからソングデータを転送することができます。転送した SMF フォーマット 0*のソングは鳴らしたり、レッスンしたりすることができます。また、コンピューターから楽器内部の内部メモリーにスタイルファイルを転送することもできます。この操作をするためには、ソング転送用アプリケーション「Musicsoft Downloader」をダウンロードし、ご使用のコンピューターにインストールする必要があります。

※ SMF フォーマット 0 は、演奏データを記録するシーケンスフォーマットの 1 つです。市販のソングデータの多くが SMF フォーマット 0 でつくられています。

■ Musicsoft Downloader をインストールする

コンピューターを使用し、インターネット上の以下の URL から Musicsoft Downloader をダウンロードします。続けてインストールを行います。

http://www.yamaha.co.jp/download/msd/

Musicsoft Downloader を使用するために必要なコンピューターシステムは、上記 URL でご確認ください。



Musicsoft Downloader はバージョン 5.6.1 以上を使用してください。

● Musicsoft Downloader を使ってファイルを送受信する

Musicsoft Downloader を使って、楽器の内部メモリーにソングファイルまたはスタイルファイルを転送します。また、バックアップデータ("ソングとステップの合格記録"を除く)を、「バックアップファイル」としてコンピューターに送信します。 Musicsoft Downloader の使用方法は、Musicsoft Downloader についているヘルプ「コンピューターと電子楽器の間でデータを転送する(プロテクトのかかっていないデータの場合)」をご参照ください。

● 楽器がコンピューターから受信できる内容

- ・ソング量: 最大 256 ファイル (ソング番号 108 ~)
- ・データ量:約1.7MB
- ・データフォーマット: SMF Format 0 と 1
- ・ファイル: 11PK3.BUP(ユーザーファイル)
 - ***.mid (MIDI ソング)
 - ***.sty(スタイルファイル)

【操作】

ファイル追加後、「電子楽器」→「Flash Memory」にファイルを移動します。



- 以下の場合は、「Musicsoft Downloader」からこの楽器にアクセスできません。
 - ・スタイルが再生しているとき
 - ソングが再生しているとき
- 楽器の操作を行うには、Musicsoft Downloader の画面を閉じて終了させる必要があります。
- ファイル名が全角文字だと転送できません。半角文字(カナ、英数字)を使用してください。



- Musicsoft Downloader でソングデータを転送するときは必ず電源アダプターを使用してください。電池でご使用中、送受信時に電池がなくなるとデータがこわれる原因になります。
- データ送信中は電源を切ったり、電源アダプターを抜き差ししないでください。送信中のデータが保存されないだけではなく、内部メモリーの動作が不安定になり、メモリー内容がすべて消える可能性があります。

● 楽器からコンピューターへ送信できる内容

- ・バックアップファイル: 11PK3.BUP (ユーザーソングを含むバックアップデータ)
- ・コンピューターから転送したソング

【操作】

「電子楽器」→「System Drive」の中にある「11PK3.BUP」をコンピューターに移動します。

● 内部メモリー内のソングデータを削除する

コンピューターから楽器へ転送したソング(ソング番号 108~)を 1 曲ずつ削除するときは、Musicsoft Downloaderの画面上で行ってください。すべての曲を削除したいときは、28 ページの「ファイルの削除」を行ってください。




- 内蔵ソングは送信できません。
- ●「ソングとステップの合格記録」はバックアップデータとして、コンピューターに保存されません。




- ユーザーソング 5 曲を含むバックアップデータは、1 つのファイルとして送受信されます。このため送受信のたびにユーザーソング 5 曲を含むバックアップデータはすべて上書きされます。
- コンピューター上でバックアップファイルをリネーム(書き換え)したり、変更しないでください。 楽器が誤動作する可能性があります。

SYSTEM BOOTING FLOWCHART



■起動フローチャート



PSPE 330/YPT-330

PARTS LIST

■ CONTENTS (目次)

OVERALL ASSEMBLY(総組立)	2
UPPER CASE ASSEMBLY (上ケース Ass'y)	4
LOWER KEY BED ASSEMBLY(下ケース鍵盤 Ass'y) 6
KEYBOARD ASSEMBLY (16N-C61-2M)	7
ELECTRICAL PARTS (電気部品)	8–12

Notes: DESTINATION ABBREVIATIONS

A: Australian model M: South African model B: British model O: Chinese model P: Brazilian model C: Canadian model D: German model Q: South-east Asia model E: European model T: Taiwan model F: French model U: U.S.A. model V: General export model (110V) H: North European model I : Indonesian model W: General export model (220V) J: Japanese model N,X: General export model K: Korean model Y: Export model


■ WARNING

Components having special characteristics are marked rianlge hinspace h

⚠ 印の部品は、安全を維持するために重要な部品です。交換する場合は、安全のために必ず指定の部品を ご使用ください。


- The numbers "QTY" show quantities for each unit.
- The parts with "--" in "PART NO." are not available as spare parts.
- This mark "}" in the REMARKS column means these parts are interchangeable.
- \bullet The second letter of the shaded ($\hfill \square$) part number is O, not zero.
- The second letter of the shaded () part number is I, not one.
- ・部品価格ランクは、変更になることがあります。
- ・QTY 欄に記されている数字は、各ユニット当たりの使用個数です。
- ・PART NO. が "--" の部品は、サービス用部品として準備されておりません。
- ・REMARKS 欄の「} | マークの部品は、併用部品です。
- ・網掛けの付いた PART NO. の 2 番目の文字は「ゼロ」ではなく、「オー」です。
- ・網掛けの付いた PART NO. の 2 番目の文字は「イチ」ではなく、「アイ」です。

■ OVERALL ASSEMBLY(総組立)




Note: Tighten this screw perpendicularly to the panel face. (注:このネジは、パネル面に対して垂直にネジ締めしてください。)

■ UPPER CASE ASSEMBLY (上ケース Ass'y)




ı	REF NO.	PART NO	DESCRIPTION		部			品			名	REMARKS	QTY	RANK
		TAITI NO.	UPPER CASE ASSEMBLY	I		ケ -	- ス			s '	<u> </u>	PSR-E333/YPT-330		TID WILL
			UPPER CASE ASSEMBLY	J						s,		PSR-E333 J (WW12200)		
			UPPER CASE ASSEMBLY	ľ						s,	У	PSR-E333 U,C,E,B,K,O,Y		
			OT LIT ONGE NOCEMBET		1-	,		. , .	٠	•	,	(WW12190)		
			UPPER CASE ASSEMBLY		1	ケ -	- ス	Δ	S	s,	V			
*	10	WW122200	UPPER CASE FINISHED	J								PSR-E333 J	ł	••••••
*	10		UPPER CASE FINISHED									PSR-E333 U,C,E,B,K,O,Y		
*	10		UPPER CASE FINISHED									YPT-330		
*	20		SP GRILLE FINISHED									PSR-E333	2	
	20		SP GRILLE FINISHED		S							YPT-330	2	06
*	40		LOUD SPEAKER	12.0cm 4ohm 3W	ス		ピ		_		カ		2	
	50	WQ354400	PN SWITCH	x1	lΡ	Ν			1	ッ	チ	Standby/On		01
*	60	WV691700	PN SWITCH	x3	Р	Ν	7		1	ッツ	チ	SONG, VOICE, STYLE		
*	70	WV691800	PN SWITCH	x12	Р	Ν	7	Z	1	"	チ	0-9,+,-		
*	80	WV691900	PN SWITCH	x2	Р	Ν	7	Z	1	ッ	チ	FUNCTION, DEMO/BGM		
*	90	WV692000	PN SWITCH	x4	Р	N		ス	1	ッツ	チ	METRONOME, TEMPO/TAP,		
												PART L,PART R		
*	100	WV692100	PN SWITCH	x3	Р	Ν	7	Z	1	ッ	チ	1 LISTENING 2 TIMING 3 WAITING,		
												KEYS TO SUCCESS, PHRASE REPEAT		
*	110	WV692200	PN SWITCH	x5	Р	Ν	7	z	1	יי	チ	A-B REPEAT, REW, FF,		
												PAUSE,START/STOP	İ	
*	120	WV692300	PN SWITCH	x3	Р	Ν	7	ス	1	ッ	チ	PORTABLE GRAND,		
												MUSIC DATABASE,		
												ULTRA-WIDE STEREO		
*	130	WV692400	PN SWITCH	x4	Р	Ν	7	z	1	ッ	チ	SPLIT,DUAL,HARMONY,TOUCH		
*	140		PN SWITCH	x1	Р	N			1	<u>.</u> ツ	チ	REC	İ	
*	200	WV926600	CIRCUIT BOARD	PNAM	Р	Ν	Α	М	シ	, –	ト	1/3-3/3		
*	300	WW021600	CRYSTAL DISPLAY	TTR2A1229	液	晶	デ・	1	ス	プレ	1		ĺ	
	310	V783800R	RUBBER CONNECTOR 105	ZTT-710	ゴ	L	\neg	ネ	5	7 タ	_]	2	03
	310	WP352300	RUBBER CNNECTOR	ZEBRA	ゴ	L	\neg	ネ	5	7 タ	_		2	
	320	V717230R	LCD HOLDER		L	C D	ホ	ル:	ダー	- — I	3 L			01
	330	WE20020R	BACK-LIT ASSEMBLY		バ	ック	ライ	1ト	Α	ss'	У			06
*	340	WV664000	CIRCUIT BOARD	DMLCD	D	M	L	С	D	シー	٠ ١			
	350	WE141400	CONNECTOR ASSEMBLY	BL 2P L=70	В		L		紡	2	材			01
	370	WE97460R	BIND HEAD TAPPING SCREW-B	4.0X8 MFZN2W3	В	タイ	1 }	+	В	1 1	1 D		8	01
	380	WE774301	BIND HEAD TAPPING SCREW-B	3.0X8 MFZN2W3	В	タイ	ſ ト	+	В	1 1	1 D		32	01
	385	WE98740R	BIND HEAD TAPPING SCREW-B	3.0X12 MFZN2W3	В	タイ	1	+	В	1 1	l D		10	01
	410		ANTIVIBRATION L		防	振	3	シ	_	۲	L	(WY04060)		
	420		ANTIVIBRATION R		防	振				۲	R	(WY04070)		
	470		CUSHION(PE)	55X25X1	ク	ッ	ショ	=	/ (Р	E)	(WW96180)		
													ļ	
													ļ	
													ļ	
													ļ	
					1									
													[
- 1				1	1							1	I	
													l	

■ LOWER KEY BED ASSEMBLY (下ケース鍵盤 Ass'y)



Γ	REF NO.	PART NO.	DESCRIPTION		部		品		名	REMARKS	QTY	RANK
Γ			LOWER KEY BED ASSEMBLY		下台	ケース	鍵盤	Ass'	У	PSR-E333/YPT-330		
			LOWER KEY BED ASSEMBLY		下台	ケース	鍵盤	Ass'	У	(WQ35360)		
	10	WD83950R	LOWER CASE F		下	ケー	ス成	形品(F)			08
	20		KEYBOARD ASSEMBLY	16N C61 P2M	1	6 N -	- C 6	1 — 2	2 M	(WE12670)		14
L	30	WE13850R	CONNECTOR ASSEMBLY	MK1 12P L=220	М	K	1	束	線			01
	40	WE13870R	CONNECTOR ASSEMBLY	MK2 5P L=250	M	K	2	束	線			01
	50	WE13880R	CONNECTOR ASSEMBLY	MK3 7P L=190	M	K	3	束	線			01
*	60	WW693500	RUBBER FOOT		ゴ		L		脚		3	
	70	WD87920R	SPRING TERMINAL A		接	点	バ	ネ	Α			01
	80	WD87930R	SPRING TERMINAL B		接	点	バ	ネ	В			01
	90		SPRING TERMINAL C		接	点	バ	ネ	С		3	01
	100		SPRING TERMINAL D		接	点	バ	ネ	D		2	01
	110	WD896800	NONWOVEN FABRIC CLOTH		不		織		布	On Battery Box	2	01
	120		CONNECTOR ASSEMBLY	BATT 3P	В	Α	Т	T 束	線	(WQ73930)		
	150	WG479400	FILAMENT TAPE	12mmX50mm	フ	ィラ	メン	トテー	- プ			
L												

KEYBOARD ASSEMBLY (16N-C61-2M)



REF NO.	PART NO.	DESCRIPTION		部	品	名	REMARKS	QTY	RANK
		KEYBOARD ASSEMBLY		1	6 N - C 6 1	- 2 M	PSR-E333/YPT-330		
		KEYBOARD ASSEMBLY	16N C61 P2M	1	6 N - C 6 1	- 2 M	(WE12670)		14
10	V3412600	WHITE KEYS	CEGB	白	鍵 C E	G B]	5	
10	WB12520R	WHITE KEYS	CEGB	白	鍵 C E	G B		5	02
20	V3412700	WHITE KEYS	DFA	白	鍵 D	F A]	5	
20	WB12530R	WHITE KEYS	DFA	白	鍵 D	F A		5	02
30	V476030R	WHITE KEY	C'	白	鍵 C	,			02
40	VZ27170R	BLACK KEYS		黒		鍵		5	02
50	V3413601	RUBBER CONTACT	16N-2M OCT	接	点ゴム16	N 2 M		4	04
60	V747740R	RUBBER CONTACT	16N-2M 13K	接	点ゴム16	N 2 M			04
80	VZ303000	FELT L WHITE	11X827	フ	ェル	ト L			02
85	VZ302901	FELT U WHITE	3.0X5X836	フ	ェル	⊦ U			02
90	WA52510R	CUSHION SHEET		ク	ッションシ	/ - F			01
100	WE774301	BIND HEAD TAPPING SCREW-B	3.0X8 MFZN2W3	В	タイト+B	I N D		7	01
110	WH899400	BIND HEAD TAPPING SCREW-P	3.0X12 MFZN2W3 SP	Р	タイト+B	I N D		13	01
120	WF49200R	BIND HEAD TAPPING SCREW-P	3.0X20 MFZN2W3	Р	タイト+B	I N D		21	01
151	V869530R	CIRCUIT BOARD	61L-MK	シ	−	1 L			04
152	V869550R	CIRCUIT BOARD	61H-MK	シ	−	1 H			06
220	V869620R	CONNECTOR ASSEMBLY	16N-2M-C61 L=210	中	継東	線			01

■ ELECTRICAL PARTS(電気部品)

DMLCD

L										
	REF NO.	PART NO.	DESCRIPTION	Γ	部	品	<u>名</u>	REMARKS	QTY	RANK
		WV664000	ELECTRICAL PARTS	DMLCD	電	気 部 M L C D シ -	品品	PSR-E333/YPT-330		
*		I	CIRCUIT BOARD CIRCUIT BOARD	DMLCD PNAM	D P	NAM > -		(WV66390)(YC994C0) 1/3-3/3 (YD033C0)		
٦			CIRCUIT BOARD	61H-MK	シ	- \ 6 1	Н	(V869540)(X2335D0)		06
			CIRCUIT BOARD	61L-MK	シ	- h 6 1	Ľ	(V869520)(X2336C0)		04
								())		
*		WV664000	CIRCUIT BOARD	DMLCD	D	M L C D シー	- ト	(WV66390)(YC994C0)		
- 1	CN101	V6802600	CONNECTOR	USB 4P SE	U	SBジャッ	ク	USB		02
- 1	CN102	VK02560R	CONNECTOR	52147 12P TE	ワ	イヤートラッ	ッ プ			01
	CN103	VK025100	CONNECTOR	52147 7P TE	ワ	イヤートラッ	y プ			01
- 1			CONNECTOR	52147 5P TE	ワ	イヤートラッ				01
- 1			CONNECTOR	52147 13P TE	ワ	イヤートラッ				01
- 1			CONNECTOR	52147 3P TE	ワ	イヤートラッ				01
- ['		I	CONNECTOR	52147 11P TE	ワチ	イヤートラ: プ + = /				01
-			CERAMIC CAPACITOR (CHIP) CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT. 100P 50V J RECT.	チ	ップセラ(ップセラ(C				UI
		I	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.		ップセラ(C				
		I	CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.		ップセラ(C				0.
			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.		ップセラ(C				
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ップセラ(F)			01
	C114	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ	ップセラ(C	H)			
	-116	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ	ップセラ(C	H)			
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.		ップセラ(ļ	01
			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ	ップセラ(C				
			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チェ	ップセラ(C				
			CAPACITOR	10 16V	チェ	ップケミコ				01
			CERAMIC CAPACITOR (CHIP)	220P 50V K RECT.	チィ	ップセラ(,			01
			CERAMIC CAPACITOR (CHIP) CERAMIC CAPACITOR (CHIP)	220P 50V K RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	220P 50V K RECT. 220P 50V K RECT.	ナチ		B) B)			01
			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ	ップセラ(C				01
			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ	ップセラ(C				
			CERAMIC CAPACITOR (CHIP)	220P 50V K RECT.	チ		в)			01
-			CERAMIC CAPACITOR (CHIP)	220P 50V K RECT.	チ		B)		·····	01
			CERAMIC CAPACITOR (CHIP)	27P 50V J RECT.	チ	ップセラ(C	,			
		I	CERAMIC CAPACITOR (CHIP)	27P 50V J RECT.	チ	ップセラ(C				
	C139	US635100	CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ッ プ セ ラ(F)			01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ		F)		ļ	01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	- '	F)			01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チェ	ップセラ(01
		I	CAPACITOR	47 6.3V	チィ	ップケミコ				01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT. 1000P 50V K RECT.	チチ	ッ プ セ ラ (ッ プ セ ラ (01
			CERAMIC CAPACITOR (CHIP) CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	ナチ	ップセラ(B)			01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT. 0.100 16V Z RECT.	ナチ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チ	ップセラ(01
-			CAPACITOR	10 16V	チ		レン			01
			CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チ	ップセラ(в)			01
			CERAMIC CAPACITOR (CHIP)	2700P 50V K RECT.	チ	ップセラ(
			CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チ	ップセラ(в)			01
			CERAMIC CAPACITOR (CHIP)	2700P 50V K RECT.	チ	ップセラ(
			CERAMIC CAPACITOR (CHIP)	2700P 50V K RECT.	チ		B)			
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ップセラ(01
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チェ	ップセラ(01
-			CAPACITOR	1 50V	チ	ップケミコ			ļ	01
			CERAMIC CAPACITOR (CHIP)	2700P 50V K RECT.	チェ	ップセラ(04
			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チチ	ップセラ(ップケミコ				01
			CAPACITOR CAPACITOR	1 50V 100 16V	ナチ	ップケミニップケミニ	1 ン			01
			CERAMIC CAPACITOR (CHIP)	0.100 16V 0.100 16V Z RECT.	チ	ップカミー				01
-			CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ		F)		ļ	01
*			CERAMIC CAPACITOR (CHIP)	0.47 10V K 1005	チ	ップセ	,			
- 1			CERAMIC CAPACITOR (CHIP)	0.47 10V K 1005	チ	ップセ	j			
	C196	WN019700	CERAMIC CAPACITOR (CHIP)	2.200 16V K RECT.	チ	ップセ	ラ			01
- 1			CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	1 -	ップセラ(C		i	ı	

*: New Parts

DMLCD

ı	REF NO.	PART NO.	DESCRIPTION		部	_		.д.		4	REMARKS	QTY	RANK
	C198		CERAMIC CAPACITOR (CHIP)	2.200 16V K RECT.	チ		ッ	<u>品</u> プ		<u>名</u>	REWIANKS	- QII	01
	C200	l	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.						. H)			0.
	C201		CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	£) H)			
	C202	l	CAPACITOR	47 6.3V	チ					コン			01
	C203	l	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ					Э Н)			
	C206		CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ) H)			
	C207		CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ					F)			01
	C209		CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ					Э Н 🤇			
	C211		CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ					Э Н)			
	C212	I	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ			セ					01
	C213		CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.						H)			
	-222		CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.						Э Н)			
	C223	I	CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ			セ					01
	-251	US635100	CERAMIC CAPACITOR (CHIP)	0.100 16V Z RECT.	チ	ッ	プ	セ	ラ (F)			01
	DA101	V9424900	DIODE ARRAY	1SS372 TE85L	ダ	1	オ	- I	ドア	レイ	1		01
*	DA101	WV973800	DIODE ARRAY	DB3J316F0L 0.10A X	ダ	1	オ	- I	・ア	レイ	J		
	DA102	V9424900	DIODE ARRAY	1SS372 TE85L	ダ	1	オ	- I	ドア	レイ			01
*	DA102	WV973800	DIODE ARRAY	DB3J316F0L 0.10A X	ダ	1	オ	- I	ドア	レイ			
	IC101	X3148A0R	IC	NT3881DFG-01	1					С	LCD DRIVER		05
	IC102	YA876A00	IC	SWL01U	1					С	CPU		
	IC103	X2590C00	IC	W9816G6IH-7	I					С	SDRAM 16M		04
	IC104	X6040A01	IC	AK4385ET	1					С	DAC		03
*	IC106	X4498A00	IC	BD5242G	1					С	CMOS Voltage Detector		
*	IC107	YD147200		MR27T6402L-3HBTNZ0	1					С	PROGRAMMED P2ROM		
	IC108	YA326A00	IC	BA4580RF-E2	1					С	OP AMP		01
	IC109	X3042E00	IC	MX29LV160DBTI-70G	I					С	FLASH ROM 16M		03
	IC110	YC287A00	IC	RP130Q181D-TR-F	1					С	REGULATOR +1.8V		01
*	IC111	YD113A00	IC	RP131H331D-T1-FE	1					С	REGULATOR +3.3V		
	L101	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チ	ツ	プ	1 :	ノダ	クタ			01
	L102	WE863900	COIL INDUCTANCE CHIP	DLP11SN900HL2L 1		Ŧ	ン‐	E —	ドコ	1 イル			01
	R101	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	-103	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R104	RF45791R	CARBON RESISTOR (CHIP)	91.0K D RECT.	チ		ツ	プ	担	抗抗			
	R105	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R106	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R107	RD455820	CARBON RESISTOR (CHIP)	820.0 63M J RECT.	チ		ツ	プ	担	抗抗		····	
	R110	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R111	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R113	RD456270	CARBON RESISTOR (CHIP)	2.7K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R114	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R115	RD45615R	CARBON RESISTOR (CHIP)	1.5K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R116	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R117	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R118	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R119	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R120	RD45612R	CARBON RESISTOR (CHIP)	1.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R121	RD456100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	チ		ツ	プ	担				01
	R122	RD458470	CARBON RESISTOR (CHIP)	470.0K 63M J RECT.	チ		ツ	プ	担	抗抗			
	R123		CARBON RESISTOR (CHIP)	470.0 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R124	RD458470	CARBON RESISTOR (CHIP)	470.0K 63M J RECT.	チ		ツ	プ	担	抗抗			
	R125	RD459100	CARBON RESISTOR (CHIP)	1.0M 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R126	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	R131	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ		ツ	プ	担				01
	R133	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ		ツ	プ	担	抗抗			01
	-135	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ		ツ	プ	担				01
	R136	I	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チ		ツ	プ	担				01
	R140	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ		ツ	プ	担				01
	-142	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ		ツ	プ	担				01
	R144	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担				01
	R146		CARBON RESISTOR (CHIP)	470.0K 63M J RECT.	チ		ツ	プ	担				
	R152		CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ		ツ	プ	担				01
	R153	l	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ		ツ	プ	担				01
	R155	l	CARBON RESISTOR (CHIP)	1.0M 63M J RECT.	チ		ツ	プ	担				01
	R156	l	CARBON RESISTOR (CHIP)	33.0 63M J RECT.	チ		ツ	プ	担				01
	R157		CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ		ツ	プ	担				01
	R158	l	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ		ツ	プ	担				01
	R160	l	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ		ツ	プ	担				01
	R162	l	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ		ツ	プ	担				01
	R163	l	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ		ツ	プ	担				01
	R164	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ		ツ	プ	担	抗抗			01
	* : New P											K: Japa	

DMLCD & PNAM

REF	NO.	PART NO.	DESCRIPTION		部		品		名	REMARKS	QTY	RANK
R1	165	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	166	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	167	RD45518R	CARBON RESISTOR (CHIP)	180.0 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	168	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	169	RD45518R	CARBON RESISTOR (CHIP)	180.0 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	170	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	171	RD456220	CARBON RESISTOR (CHIP)	2.2K 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	172	RD45518R	CARBON RESISTOR (CHIP)	180.0 63M J RECT.	1	ツ	プ	抵	抗			01
R1	173	RD45518R	CARBON RESISTOR (CHIP)	180.0 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	174	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ	ツ	プ	抵	抗			01
R1	175	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	1	ツ	プ	抵	抗			01
R1	176	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	1	ツ	プ	抵	抗			01
R1	177	RD456100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.		ツ	プ	抵	抗			01
R1	178	RD45615R	CARBON RESISTOR (CHIP)	1.5K 63M J RECT.	ı	ツ	プ	抵	抗			01
	180		CARBON RESISTOR (CHIP)	1.0K 63M J RECT.		ツ	プ	抵	抗			01
R1	183	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	1	ツ	プ	抵	抗			01
-1	88	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	ı	ツ	プ	抵	抗			01
R1	190	RD456100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.		ツ	プ	抵	抗			01
R1	192		CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ツ	プ	抵	抗			01
	98		CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ツ	プ	抵	抗			01
- 1	200		CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	ı	ツ	プ	抵	抗			01
- 1	202	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.		ツ	プ	抵	抗			01
- 1	101	WH209400	RESISTOR ARRAY	1.0K X 4		抗	ア	レ	1			
- 1	03	WH209400	RESISTOR ARRAY	1.0K X 4		抗	ア	レ	1			
	104	WH213400	RESISTOR ARRAY	47K X 4		抗	ア	レ	1			01
-1	06	WH213400	RESISTOR ARRAY	47K X 4		抗	ア	レ	1			01
RA	107	WH207000	RESISTOR ARRAY	100 X 4		抗	ア	レ	1			01
-1	09	WH207000	RESISTOR ARRAY	100 X 4		抗	ア	レ	1			01
- 1		WH213400	RESISTOR ARRAY	47K X 4		抗	ア	レ	1			01
	17	WH213400	RESISTOR ARRAY	47K X 4		抗	ア	レ	1			01
	101	VV556400	TRANSISTOR	2SC2412K Q,R,S TP	トラ:			2				01
- 1	102	VV556500	TRANSISTOR	2SA1037AK Q,R,S TP	トラ:				SA			01
TR	103	VV556500	TRANSISTOR	2SA1037AK Q,R,S TP	トラ:				SA			01
- 1	104	VV556400	TRANSISTOR	2SC2412K Q,R,S TP	トラ:				S C			01
	101	WE19440R	QUARTZ CRYSTAL UNIT	16.9344MHz HC-49S-SM		晶	振	動	子			01
* X1	102	WV922800	RESONATOR CERAMIC	48MHz CSTCW48M0XZ301	セラ	Ξ,	ッ ク	振重	助 子			
*		WV926600	CIRCUIT BOARD	PNAM	P N			シー		1/3-3/3 (YD033C0)		
			SILICON GREASE	G-746	シリ	\neg		グリ		(0412125)		
			SILICON GREASE	X-113A G746	シリ			グリ		(VA79810)		
		WE774301	BIND HEAD TAPPING SCREW-B	3.0X8 MFZN2W3	ı			3 I I			3	01
	516	UR849100	ELECTROLYTIC CAPACITOR	1000 25.0V RX TP	ケ	Ξ.		コ	、ン			01
- 1	202	V1878000	CONNECTOR	51048 2P TE	ケー			ルタ				01
- 1	301	VI879100	CONNECTOR	51048 13P TE	ケー			ルタ				01
	303	V1878800	CONNECTOR	51048 10P TE				ルク				01
- 1	304	VI878100	CONNECTOR	51048 3P TE	1 '			ルタ				01
- 1	401		CONNECTOR	51048 5P TE	ケー	-	-					01
			CONNECTOR	52147 2P TE	ワイ							01
	502	V1878800	CONNECTOR	51048 10P TE	ケー	-	-					01
	503		CONNECTOR	51048 11P TE	ケー							01
	504		CONNECTOR	51048 5P TE	ケー							01
- 1	505		CONNECTOR	51048 2P TE	ケー							01
	506	VL844700	CONNECTOR	XH 3P TE	ベー							01
- 1	505	WV008800		2A02-A0 TE-52	1	1	オー	_	ド			
	501	WY516700		TSD 2A 250V (P)	ヒ그	_ ;	٨ 2	5 (DECUMATOR 51		01
- 1		X9491A00		KIA78D05PI-U/P					С	REGULATOR +5V		
	502	XV771A00		BA5417 5.0W 2ch	[]		٠.	<i>-</i> ,	C	POWER AMP 2.5W X 2		03
- 1	303		CONNECTOR	JACK YKB21-5014	ホー					SUSTAIN		01
	501	VV943300	CONNECTOR	HTJ064-04A	I .			ネク		PHONES/OUTPUT		02
	502	V655760R	CONNECTOR	HTJ-020-05AZ	電源	Ī =		ク		DC IN		04
	501		HEAT SINK		放	_	熱		板	(WY45590)		
- 1	502	 VT07000D	PLATE FOR EMC	El EDOGGON CO ::	1		対		三具工法	(WY45760)		
	501	VT27920R	COIL	FL5R200QN 20uH	コイ		2 0		天津			01
- 1	502	VT27920R	COIL	FL5R200QN 20uH	コイ:		2 0		天津			01
	502	WD92690R	TRANSISTOR	2SB1342	トラニ				SB	 		02
	401	WC70980R	ROTARY VARIABLE RESISTOR	A 5.0K XV014111YGP				J — '		MUSTER VOLUME		02
	1103		CONNECTOR ASSEMBLY	AMDM 11P	ı) M			(WQ66100)		
	1104		CONNECTOR ASSEMBLY	PN1 10P	l	N	1	線	材	(WQ66030)		
	1105		CONNECTOR ASSEMBLY	MVR 5P	ı	V	R	線	材	(WQ66120)		
WH	1201		CONNECTOR ASSEMBLY	SP 2P	S	Р		線	材	(WQ66140)		

*: New Parts

RANK: Japan only

<u>^</u>

 \triangle

PNAM

Г	REF NO.	PART NO.	DESCRIPTION		部			F	1.		名	REMARKS	QTY	RANK
	/H202		CONNECTOR ASSEMBLY	SP 2P	S		F	F	終		_ 材	(WQ66140)	Q11	HANK
- 1	/H301		CONNECTOR ASSEMBLY	PN2 13P	P		Ν.	2		線	材	(WQ66060)		
	/H302		CONNECTOR ASSEMBLY	JACK 3P	J	1	۸.	С	K	線	材	(WW15820)		
- 1			JUMPER CABLE	0.55 TIN	ジ		7	シ	18	_	線	(VA07890)		
- 1	C501	UR838470	ELECTROLYTIC CAPACITOR	470.00 16.0V RX TP	ケ		3		=]	ン	` ´		01
	C502	VC69480R	SEMICONDUCTOR CERAMIC CAP.	0.1000 25V Z TATET	半	導	乜	t t	2 5	, J	ン			01
- [(C504	UR866100	ELECTROLYTIC CAPACITOR	1.00 50.0V RX TP	ケ		3		=]	ン			01
- 1 (C505	UR866100	ELECTROLYTIC CAPACITOR	1.00 50.0V RX TP	ケ		3		=	1	ン			01
* (C506	WW465600		470P 63V K TATETE-	セ		=	7	=]	ン			
	C508	VC69480R		0.1000 25V Z TATET	半	導	1/2	t	2 5	, _–				01
- 1	C510		ELECTROLYTIC CAPACITOR	47.00 16.0V RX TP	ケ		3		=		ン			01
	C512		CERAMIC CAPACITOR	470P 63V K TATETE-	12		=		=		ン			
	C513		ELECTROLYTIC CAPACITOR	47.00 16.0V RX TP	ケ		3		Ξ		ン			01
	C514		ELECTROLYTIC CAPACITOR	100.00 16.0V RX TP	f		3		Ξ		ン			01
	C515		ELECTROLYTIC CAPACITOR	100.00 16.0V RX TP	ケ	₩.			_ =		, 、、			01
- 1	C519		MONOLITHIC POLYESTER F. CAP.	0.15 50V J RX TP	積	層		1	-	_ =	レン			01
	C520 C521	VE326200	ELECTROLYTIC CAPACITOR MONOLITHIC POLYESTER F. CAP.	100.00 16.0V RX TP 0.15 50V J RX TP	ケ	層	7	1	_ = ラ	_ =	レン			01 01
	C522		ELECTROLYTIC CAPACITOR	470.00 16.0V RX TP	ケ	眉	` .				· '\			01
	C523		ELECTROLYTIC CAPACITOR	470.00 16.0V RX TP	1 'r		-		Ξ		ン			01
	C524		ELECTROLYTIC CAPACITOR	47.00 16.0V RX TP	ケ			• :	=		ン		ļ	01
- 1	C525		ELECTROLYTIC CAPACITOR	47.00 16.0V RX TP	1				Ξ		ン			01
	C530		SEMICONDUCTOR CERAMIC CAP.	0.1000 25V Z TATET	半	導					ン			01
	-534		SEMICONDUCTOR CERAMIC CAP.	0.1000 25V Z TATET	半		1/2			, _	ン			01
	D302	VD631600		1SS133,176,HSS104	ダ		1	7		_	ĸ			01
	-306	VD631600	DIODE	1SS133,176,HSS104	ダ		1	7		_	ド			01
	D502	VD631600	DIODE	1SS133,176,HSS104	ダ		1	7	t	_	ド			01
	-504	VD631600	DIODE	1SS133,176,HSS104	ダ		1	7	t	_	ĸ			01
	J301		JUMPER CABLE	0.55 TIN	ジ	4	7	ン	/۱	_	線	(VA07890)		
	J302		JUMPER CABLE	0.55 TIN	ジ		7	ン	/۱	_	線	(VA07890)		
	J502		JUMPER CABLE	0.55 TIN	ジ		7	ン	18	_	線	(VA07890)		
- 1	-507		JUMPER CABLE	0.55 TIN	ジ		7	ン	۱۱°	_	線	(VA07890)		
- 1	R309		JUMPER CABLE	0.55 TIN	ジカ		7	ンェ	//	+110	線	(VA07890)		04
- 1	R501 R501	HF455180 V254830R		180.0 1/4 J AX TP	カ	_		ボボ	ンン	抵抵	抗 抗	}		01
	R502		CARBON RESISTOR CARBON RESISTOR	180.0 1/6J 26TP 180.0 1/4 J AX TP	カ			ボ	ン	抵	抗抗			01
- 1	R502		CARBON RESISTOR	180.0 1/6J 26TP	1,7	_		ボ	ン	抵	抗抗	}		01
- 1	R503		CARBON RESISTOR	10.0K 1/4 J AX TP	カ	_		ボ	シ	抵	抗	lí		01
- 1	-506	HF45710R		10.0K 1/4 J AX TP	カ	-	_	ボ	ン	抵	抗			01
	R503	V255040R	CARBON RESISTOR	10.0K 1/6J 26TP	カ	-	-	ボ	ン	抵	抗			
	-506	V255040R	CARBON RESISTOR	10.0K 1/6J 26TP	カ	-	-	ボ	ン	抵	抗	J		
	R507		CARBON RESISTOR	470.0 1/4 J AX TP	カ	-	-	ボ	ン	抵	抗]]		01
	R507	V254880R		470.0 1/6J 26TP	カ	-		ボ	ン	抵	抗	Į		
	R508		CARBON RESISTOR	1.0K 1/4 J AX TP	カ	-		ボ	ン	抵	抗]		01
	R508		CARBON RESISTOR	1.0K 1/6 J 26TP	カ	<u>-</u>		ボ	ン	抵	抗	[]		
	R509		CARBON RESISTOR	1.0K 1/4 J AX TP	カ	-		ボギ	ン	抵	抗	}		01
	R509		CARBON RESISTOR	1.0K 1/6 J 26TP	カカ	-		ボギ	ン	抵	抗姑	{		01
			CARBON RESISTOR CARBON RESISTOR	470.0 1/4 J AX TP 470.0 1/6J 26TP	カカカ					抵抵				01
	R510		FLAME PROOF CARBON RESISTOR							払ン担		[
			CARBON RESISTOR	47.0K 1/4 J AX TP	カ		-			抵				01
- 1	- 1		CARBON RESISTOR	47.0K 1/6J 26TP	カ		_			抵	抗抗	<u> </u> }		
- 1	R513		FLAME PROOF CARBON RESISTOR	2.2 1/4 J T26						ン担		[
	R514	HF455330	CARBON RESISTOR	330.0 1/4 J AX TP	カ			ボ		抵	抗	[01
			CARBON RESISTOR	330.0 1/6J 26TP	カ			ボ	ン	抵	抗			
	- 1		CARBON RESISTOR	330.0 1/4 J AX TP	カ			ボ	ン	抵	抗]		01
- 1			CARBON RESISTOR	330.0 1/6J 26TP	カ	-		ボ	ン	抵	抗	[{		
	- 1		CARBON RESISTOR	18.0K 1/4 J AX TP	カ	-		ボギ	ン	抵	抗	}		01
	R516 R517		CARBON RESISTOR CARBON RESISTOR	18.0K 1/6J 26TP	カカカ	_		ボボ	ンン	抵抵	抗抗	{		01
	R517		CARBON RESISTOR	12.0K 1/4 J AX TP 12.0K 1/6J 26TP	カ			ボボ	ン	抵	抗			UI
- 1	- 1		CARBON RESISTOR	47.0K 1/4 J AX TP	カ			ボ	ン	抵抵	抗抗	lí l		01
- 1	- 1		CARBON RESISTOR	47.0K 1/6J 26TP	カ	_		ボ	ン	抵	抗抗	}		,
- 1	- 1		CARBON RESISTOR	100.0 1/4 J AX TP	カ	-		ボ	シ	抵	抗抗	Įį l		01
	R519		CARBON RESISTOR	100.0 1/6J 26TP	カ	-		ボ	ン	抵	抗]		
	- 1		CARBON RESISTOR	100.0 1/4 J AX TP	カ	-	-	ボ	ン	抵	抗]		01
	R520		CARBON RESISTOR	100.0 1/6J 26TP	カ	-		ボ	ン	抵	抗	ĮĮ		
- 1	- 1		CARBON RESISTOR	3.3K 1/4 J AX TP	カ	-		ボ	ン	抵	抗	}		01
	R521		CARBON RESISTOR	3.3K 1/6 J 26TP	カカ	_		ボギ	ン	抵	抗姑	[{		0.1
	R523		CARBON RESISTOR	47.0K 1/4 J AX TP	カ	_	_	ボ	ン	抵	抗	BANK.		01

*: New Parts

PNAM and 61H-MK and 61L-MK

RE	EF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	QTY	RANK
F	3523		CARBON RESISTOR	47.0K 1/6J 26TP	カーボン抵抗			
			TRANSISTOR	2SC1740S R,S	トランジスタ 2 S C	ĺ		01
1	1301	10174070	11000001011	2001740011,0				"
		VOCOEEOD	CIRCUIT BOARD	61H-MK	シート 6 1 H	(V869540)(X2335D0)		06
1	101		l	52147 12P TE	1	(\$609340)(\$233500)		l .
	N01		CONNECTOR		<u> </u>			01
	N02		CONNECTOR	52147 5P TE	ワイヤートラップ。			01
	N03		CONNECTOR	52147 12P TE	ワイヤートラップ			01
	0073	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド			01
-	122	VB941200		1SS133,1SS176 TE-5	ダ イ オ ー ド			01
	0073	WP977700	DIODE	HSS4148TA-E Q TE	ダ イ オ ー ド			
-	122	WP977700	DIODE	HSS4148TA-E Q TE	ダ イ オ ー ド			
		V869530B	CIRCUIT BOARD	61L-MK	シート 6 1 L	(V869520)(X2336C0)		04
ا ر	N04		CONNECTOR	52147 12P TE	ワイヤートラップ	(**************************************		01
			CONNECTOR	52147 7P TE	1			01
	0001	VB941200		1SS133,1SS176 TE-5	ダ イ オ ー ド			01
	072	VB941200		1SS133,1SS176 TE-5	ダ イ オ ー ド] }		01
	0001	WP977700		HSS4148TA-E Q TE	ダ イ オ ー ド			
1 -	072	WP977700	DIODE	HSS4148TA-E Q TE	ダ イ オ ー ド	J		
ķ		YD136A00	LOUD SPEAKER	12.0cm 4ohm 3W	スピーカ		2	
ŧ			CRYSTAL DISPLAY	TTR2A1229	液晶ディスプレイ			
		***************************************	OTTIONAL BIOLEXT	11112/11223				
ļ					-			
1								
1								
1								
1								
1								
1								
1								
1								
1								
							l	
1								
1								
1								
1								
1								
1								
					-			
1								
1								
1								
1								
1								
1								
1								
1								
1								
1								
1								
1								
1								
_	Now P			•	•	BANK:		

